YAMAHA

PARTS CATALOGUE

XT660Z (11D8) EUROPE

1K11D-300EA

( )

YAMAHA GENUINE Parts & Accessories

XT660Z
PARTS CATALOGUE
©2011 by Yamaha Motor España S.A.
1st edition, May 2011
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor España S.A.
is expressly prohibited.
Printed in Spain.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.

   "UR" Use specified parts number.
   "UN" Use as many as needed.
   "AP" Alternate Parts
   "LM" Locally Made (Parts need to be ordered locally)
   "F#" Frame No. (Applicable machine No.)
   "O/S" Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5–83310–60	FRONT FLASHER LIGHT ASSY	2	
115–83311–60	.BULB (6V–18W)	1	

4. Applicable colours of graphics are represented in the "REMARKS" as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4–24110–00–X5	FUEL TANK COMP.	2	MXR
3J1–24240–10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.


6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



Frame Serial No.




8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
BMC(*)	BLUE METALLIC C	0775
LGB	LOW GLOSS BLACK	0098
SMX(*)	BLACK METALLIC X	0903


MODEL LABEL

(1) A label called “Model Label” is affixed in the location as indicated in (3) below.
When using this parts catalogue, please be sure to cross–reference the “model code – production code No.” in the catalogue with the “model code – production code No.” indicated on the Model Label affixed onto the product concerned.


(2) “Model Label” Indication



a: Model Type Code
b: Production Code No.
c: Colouring Type



(3) Model Label Affixing Location



(4) Colouring Information

Model Code	Colouring Type Code	Colour Code	Colour Name	Abbreviation
11D8	A	0775	BLUE METALLIC C	BMC
	B	0903	BLACK METALLIC X	SMX

(5) Model Code – Production Code Number of Model Listed in This Parts Catalogue

Model Code	Production Code No.	Country (destination)
11D8	010	AUSTRIA
		CZECHO
		DENMARK
		FINLAND
		FRANCE
		GERMANY
		GREECE
		HUNGARY
		IRELAND
		ITALY
		NORWAY
		POLAND
		SLOVENIA
		SOUTH AFRICA
		SPAIN
		SWEDEN
		SWITZERLAND
		UNITED KINGDOM
	020	BELGIUM
		NETHERLANDS
	030	PORTUGAL

Model Code	Production Code No.	Country (destination)

CONTENTS

ENGINE


CYLINDER HEAD 1
CYLINDER 2
CRANKSHAFT & PISTON 3
VALVE 4
CAMSHAFT & CHAIN 5
WATER PUMP 6
RADIATOR & HOSE 7
OIL PUMP 9
INTAKE 11
INTAKE 2 13
AIR INDUCTION SYSTEM 14
EXHAUST 15
CRANKCASE 17
CRANKCASE COVER 1 18
STARTER 20
CLUTCH 21
TRANSMISSION 23
SHIFT CAM & FORK 25
SHIFT SHAFT 26

CHASSIS

FRAME 27
FENDER 29
REAR ARM 30
REAR SUSPENSION 32
STEERING 33
FRONT FORK 34
FUEL TANK 36
SEAT 38
FRONT WHEEL 40
FRONT BRAKE 41
REAR BRAKE 42
REAR WHEEL 43
STEERING HANDLE & CABLE 45
FRONT MASTER CYLINDER 46
STAND & FOOTREST 47
REAR MASTER CYLINDER 49
COWLING 51
GENERATOR 52
FLASHER LIGHT 53
METER 54
HEADLIGHT 55
TAILLIGHT 56
HANDLE SWITCH & LEVER 58
ELECTRICAL 1 59
ELECTRICAL 2 61

INDEX


NUMERICAL INDEX 63



11D8300-K010

FIG. 1 CYLINDER HEAD


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E1101–02	CYLINDER HEAD ASSY	1					
2	4G0–11133–11	.GUIDE, VALVE 1	4					
3	95617–08618	BOLT, STUD	4					
4	5VK–11181–00	GASKET, CYLINDER HEAD 1	1					
5	90105–09002	BOLT, FLANGE	2					
6	90105–09004	BOLT, FLANGE	2					
7	90105–09003	BOLT, FLANGE	2					
8	91317–06030	BOLT	2					
9	90201–096J9	WASHER, PLATE	6					
10	94701–00X09	PLUG, SPARK (NGK CR7E)	1					
11	93612–16X00	PIN, DOWEL	2					
12	5VK–E1185–00	COVER, CYLINDER HEAD SIDE 3	1					
13	93210–96X00	O-RING	1					
14	95027–06020	BOLT, FLANGE	2					
15	90465–10044	CLAMP	1					
16	5VK–E1186–00	COVER, CYLINDER HEAD SIDE 2	2					
17	93210–78X00	O-RING	2					
18	91317–06018	BOLT	8					



11D6300-J020

FIG. 2 CYLINDER


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–11311–00	CYLINDER 1	1					
2	5VK–11351–00	GASKET, CYLINDER	1					
3	90105–10078	BOLT, FLANGE	2					
4	90105–10077	BOLT, FLANGE	2					
5	90201–101A4	WASHER, PLATE	4					
6	91317–06040	BOLT	2					
7	90465–10045	CLAMP	1					



11D6300-J030

FIG. 3 CRANKSHAFT & PISTON


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–11400–01	CRANKSHAFT ASSY	1					
2	5VK–11401–09	.CRANK SUB ASSY 1	1					
3	5VK–11422–00	.CRANK 2	1					
4	5VK–11681–01	.PIN, CRANK 1	1					
5	93310–84010	.BEARING	1					
6	5VK–11651–00	.ROD, CONNECTING	1					
7	90280–05001	KEY, WOODRUFF	1					
8	90201–16013	WASHER, PLATE	1					
9	90179–16448	NUT	1					
10	93306–308Y0	BEARING	1					
11	5VK–11631–00	PISTON (STD)	1					
12	5VK–11603–00	PISTON RING SET (STD)	1					
13	5VK–11633–00	PIN, PISTON	1					
14	93450–24824	CIRCLIP	2					
15	90201–30X00	WASHER, PLATE	1					
16	5VK–E1536–00	GEAR, DRIVE	1					
17	5VK–E1531–00	GEAR, BALANCE WEIGHT	1					
18	5VK–E1454–00	WEIGHT 1	1					
19	93306–305YJ	BEARING	1					
20	93306–305YH	BEARING	1					
21	93101–25106	OIL SEAL	1					
22	90282–05058	KEY, STRAIGHT	1					
23	90170–18003	NUT	1					
24	90215–18X00	WASHER, LOCK	1					



11D6300-J040

FIG. 4 VALVE

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–12111–00	VALVE, INTAKE	2					
2	5VK–12121–00	VALVE, EXHAUST	2					
3	5VK–12113–00	SPRING, VALVE INNER	4					
4	3YF–12116–00	SEAT, VALVE SPRING	4					
5	5H0–12119–00	SEAL, VALVE STEM	4					
6	3YF–12117–01	RETAINER, VALVE SPRING	4					
7	4G0–12118–00	COTTER, VALVE	8					
8	5VK–E2151–00	ARM, VALVE ROCKER	1					
9	5VK–E2161–00	ARM, VALVE ROCKER 2	1					
10	5VK–12146–00	SHAFT, ROCKER	2					
11	5BP–12159–01	SCREW, VALVE ADJUSTING	4					
12	90170–06128	NUT	4					




11D6300-J050

FIG. 5 CAMSHAFT & CHAIN


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E2170–20	CAMSHAFT ASSY 1	1					
2	93306–07209	.BEARING	1					
3	5VK–12284–00	PIN, DECOMPRESSION LEVER	1					
4	5VK–12290–00	LEVER, DECOMPRESSION SPRING	1					
5	5VK–12280–01	DECOMPRESSION ASSY	1					
6	5VK–E111F–00	PLATE	1					
7	95027–06012	BOLT, FLANGE	2					
8	90105–07004	BOLT, FLANGE	2					
9	94591–57126	CHAIN (98XRH2010-126M)	1					
10	5VK–E2231–00	GUIDE, STOPPER 1	1					
11	5VK–E2241–00	GUIDE, STOPPER 2	1					
12	90119–06X05	BOLT, WITH WASHER	2					
13	5VK–E2210–00	TENSIONER ASSY, CAM CHAIN	1					
14	91317–06025	BOLT	2					
15	4DW–12213–00	GASKET, TENSIONER CASE	1					

FIG. 6 WATER PUMP



11D6300-J060


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E2436–00	GEAR, DRIVE	1					
2	5VK–12450–00	IMPELLER SHAFT ASSY	1					
3	5VK–12422–00	COVER, HOUSING	1					
4	93210–61750	O-RING	1					
5	93306–00106	BEARING	1					
6	5VK–12421–00	HOUSING, WATER PUMP	1					
7	95027–06025	BOLT, FLANGE	2					
8	93101–12173	OIL SEAL	1					
9	11H–12438–10	SEAL, MECHANICAL	1					
10	90201–12541	WASHER, PLATE	1					
11	5VK–12428–00	GASKET, HOUSING COVER 2	1					
12	90430–06014	GASKET	1					
13	93603–16219	PIN, DOWEL	1					
14	5VK–12459–00	GEAR, IMPELLER SHAFT	1					
15	99009–12400	CIRCLIP	1					
16	5VK–E2469–00	JOINT 1	1					
17	91317–06020	BOLT	2					
18	93210–33X00	O-RING	1					
19	5VK–12481–00	PIPE 1	1					
20	93210–21X00	O-RING	1					
21	91317–06012	BOLT	1					
22	5VK–E2577–10	HOSE 2	1					
23	90450–32X03	HOSE CLAMP ASSY	2					
24	91317–06050	BOLT	3					



11D8300-K070

FIG. 7 RADIATOR & HOSE


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–12410–00	THERMOSTAT ASSY	1					
2	5VK–E2413–00	COVER, THERMOSTAT	1					
3	95027–06020	BOLT, FLANGE	2					
4	93210–41X00	O-RING	1					
5	11D–E2578–00	HOSE 3	1					
6	90450–32X03	HOSE CLAMP ASSY	1					
7	90450–32X03	HOSE CLAMP ASSY	1					
8	11D–E2461–01	RADIATOR COMP	1					
9	11D–E2405–00	BLOWER ASSY	1					
10	5VK–E2462–00	CAP, RADIATOR	1					
11	5B2–E2675–00	BOLT, BLOWER HOLDING	2					
12	5B2–E2623–00	BOLT	1					
13	5B2–E2671–00	NUT 1	3					
14	11D–E2662–00	COLLAR 1	3					
15	11D–F8345–00	MOLE 1	2					
16	56P–E2465–00	DAMPER, RADIATOR	2					
17	11D–E240J–00	RADIATOR COVER ASSY1	1					
18	90111–06X19	BOLT,HEX. SOCKET BUTTON	3					
19	90387–06X02	COLLAR	3					
20	11D–E240K–00	RADIATOR COVER ASSY 2	1					
21	90111–06X19	BOLT,HEX. SOCKET BUTTON	1					
22	90111–06X17	BOLT,HEX. SOCKET BUTTON	2					
23	90269–07007	RIVET	2					
24	90387–06X02	COLLAR	3					
25	11D–E2579–00	HOSE 4	1					
26	90450–32X03	HOSE CLAMP ASSY	1					
27	90450–32X03	HOSE CLAMP ASSY	1					



11D8300-K070

FIG. 7 RADIATOR & HOSE


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	90480–18276	GROMMET	2					
29	90387–06042	COLLAR	2					
30	90111–06X20	BOLT,HEX. SOCKET BUTTON	2					
31	90480–15363	GROMMET	1					
32	11D–E2498–00	PROTECTOR	1					
33	90111–06X19	BOLT,HEX. SOCKET BUTTON	2					
34	90387–06648	COLLAR	2					
35	2VW–F1736–00	NUT,PLATE	2					
36	11D–F1871–00	TANK, RECOVERY	1					
37	90110–06202	BOLT, HEXAGON SOCKET HEAD	3					
38	90480–14014	GROMMET	3					
39	90387–06161	COLLAR	3					
40	5DS–F1771–00	BODY, CAP	1					
41	11D–F1873–00	BRACKET, RECOVERY TANK	1					
42	90445–08X05	HOSE	1					
43	90467–08003	CLIP	2					
44	90445–08X06	HOSE	1					
45	90467–08003	CLIP	1					
46	90464–08126	CLAMP	1					



11D6300-J080

FIG. 8 OIL PUMP


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E3300–00	OIL PUMP ASSY	1					
2	5LP–13329–00	GASKET, PUMP COVER	1					
3	93210–13X00	O-RING	2					
4	92017–06035	BOLT, BUTTON HEAD	3					
5	3AJ–13325–00	GEAR, PUMP DRIVEN	1					
6	93410–11X00	CIRCLIP	1					
7	5VK–E3356–00	COVER, PUMP 2	1					
8	5VK–E3327–00	COVER, PUMP GEAR	1					
9	91317–05008	BOLT	2					
10	5VK–WE343–00	STRAINER COMP.	1					
11	5VK–E3415–10	SEAL, OIL STRAINER	1					
12	91317–06020	BOLT	3					
13	90340–14132	PLUG, STRAIGHT SCREW	1					
14	214–11198–01	GASKET	1					
15	5VK–E3181–00	PIPE, DELIVERY 3	1					
16	93210–11X00	O-RING	2					
17	4X7–13440–01	ELEMENT ASSY, OIL CLEANER	1					
18	2WK–13447–00	COVER, OIL ELEMENT	1					
19	93210–64X01	O-RING	1					
20	93210–07X01	O-RING	1					
21	90109–06419	BOLT	1					
22	91317–06095	BOLT	2					
23	90149–05110	SCREW	1					(M5 BOLT)
24	90430–05X00	GASKET	1					
25	5VK–13161–00	PIPE, DELIVERY 1	1					
26	90401–08133	BOLT, UNION	2					
27	90430–08X01	GASKET	4					



11D6300-J080

FIG. 8 OIL PUMP


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	5VK–13171–00	PIPE, DELIVERY 2	1					
29	90401–10096	BOLT, UNION	2					
30	90430–10X00	GASKET	4					
31	91317–06012	BOLT	1					
32	583–13113–00	SEAT, CHECK BALL	1					
33	93503–08007	BALL	1					
34	90501–04X01	SPRING, COMPRESSION	1					
35	5VK–13464–00	HOSE, OIL 1	1					
36	93210–10X00	O-RING	1					
37	91810–14X00	PIN, DOWEL	1					
38	91317–06025	BOLT	1					
39	11D–13405–00	OIL PIPE COMP. 1	1					
40	11D–13467–00	HOSE	1					
41	93210–15X00	O-RING	1					
42	91317–06016	BOLT	2					
43	90445–11X01	HOSE	1					
44	90467–10008	CLIP	1					
45	90450–20X01	HOSE CLAMP ASSY	1					
46	90467–10008	CLIP	1					



11D6300-J090

FIG. 9 INTAKE


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E3586–10	JOINT, CARBURETOR 1	1					
2	90450–72003	HOSE CLAMP ASSY	2					
3	11D–E4411–00	CASE, AIR CLEANER 1	1					
4	11D–E441A–00	COVER, CLEANER CASE 1	1					
5	11D–E441E–00	COVER, CLEANER CASE 2	1					
6	11D–E4453–00	JOINT, AIR CLEANER 1	1					
7	11D–E4452–00	SEAL	1					
8	9770M–50030	SCREW, TAPPING	13					
9	11D–E4451–00	ELEMENT, AIR CLEANER	1					
10	11D–E4430–00	DUCT ASSY	1					
11	11D–E4457–00	SEAL	1					
12	11D–E443E–00	PIPE, DRAIN	1					
13	90467–11090	.CLIP	1					
14	90467–12085	CLIP	1					
15	11D–E1167–00	PIPE, BREATHER 2	1					
16	90467–17801	CLIP	1					
17	90467–14800	CLIP	1					
18	92507–06012	SCREW, PAN HEAD	4					
19	92907–06600	WASHER, PLATE	4					
20	90450–59001	HOSE CLAMP ASSY	1					
21	5YK–E243A–10	HOSE 1	1					
22	5YK–E244G–00	HOSE, 4	1					
23	90467–11090	CLIP	1					
24	90467–11108	CLIP	2					
25	90467–11108	CLIP	1					
26	11D–E3545–00	HOSE 1	1					
27	90467–170A2	CLIP	1					



11D6300-J090

FIG. 9 INTAKE


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	90467–17128	CLIP	1					
29	11D–E3542–00	HOSE, VACUUM SENSING 1	1					
30	90467–07138	CLIP	2					
31	11D–E5371–11	BREATHER	1					
32	90111–06051	BOLT,HEX. SOCKET BUTTON	3					
33	90387–068P7	COLLAR	1					
34	90387–07037	COLLAR	4					
35	9131L–06035	BOLT	1					
36	90480–18276	GROMMET	4					



11D6300-J100

FIG. 10 INTAKE 2


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5YK–13750–11	THROTTLE BODY ASSY	1					
2	5VK–13160–00	.DELIVERY PIPE ASSY 1	1					
3	90430–09002	.GASKET	1					
4	98507–06012	.SCREW, PAN HEAD	2					
5	8CC–14216–10	.SCREW	2					
6	56B–14503–00	.ADJUST SCREW SET	1					
7	5VK–14531–00	..SPRING, ADJUST SCREW	1					
8	5VK–13761–00	.INJECTOR	1					
9	5PS–14147–00	..O-RING	1					
10	3P6–85885–00	.THROTTLE SENSOR ASSY	1					



11D6300-J110

FIG. 11 AIR INDUCTION SYSTEM

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–14871–02	PIPE 1	1					
2	5VK–14815–00	GASKET	1					
3	91380–06016	BOLT	2					
4	11D–E4881–00	HOSE, BEND 1	1					
5	90467–17089	CLIP	2					
6	5VK–14803–00	AIR INDUCTION SYSTEM ASSY	1					
7	11D–E4882–00	HOSE, BEND 2	1					
8	90467–17089	CLIP	1					
9	90467–170A0	CLIP	1					




11D8300-K120

FIG. 12 EXHAUST


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–E4611–00	PIPE, EXHAUST 1	1					
2	5YK–E4612–00	NUT, RING	1					
3	5YK–E477R–00	BAND 1	1					
4	90105–08X20	.BOLT, FLANGE	1					
5	1B9–8592A–00	SENSOR, OXYGEN	1					
6	11D–E4621–00	PIPE, EXHAUST 2	1					
7	4EL–14714–00	GASKET, MUFFLER	1					
8	5YK–E477T–00	BAND 2	1					
9	90105–08X20	.BOLT, FLANGE	1					
10	11D–E4628–00	PROTECTOR, EXHAUST PIPE	1					
11	11D–E113B–01	INSULATOR 3	1					
12	4EL–14714–00	GASKET, MUFFLER	1					
13	11D–E4631–01	PIPE, EXHAUST 3	1					
14	11D–E4715–00	BAND, MUFFLER	1					
15	90105–08X20	.BOLT, FLANGE	1					
16	5YK–E4714–00	GASKET, MUFFLER	1					
17	91380–08020	BOLT	1					
18	5CH–E4766–00	WASHER, PROTECTOR	1					
19	11D–E4710–20	MUFFLER ASSY 1	1					
20	2VW–F1736–00	NUT,PLATE	6					
21	3YF–14613–01	GASKET, EXHAUST PIPE	2					
22	90179–08442	NUT	4					
23	11D–E4708–01	PROTECTOR ASSY	1					
24	11D–E4718–00	.PROTECTOR, MUFFLER 1	1					
25	11D–E4787–00	.CAP, SILENCER	1					
26	90267–40X01	.RIVET, BLIND	4					
27	9290L–04600	.WASHER	4					

FIG. 12 EXHAUST



11D8300-K120

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	11D–E111B–01	.INSULATOR 1	1					
29	11D–E4708–11	PROTECTOR ASSY	1					
30	11D–E4728–00	.PROTECTOR, MUFFLER 2	1					
31	11D–E4798–00	.CAP, SILENCER 2	1					
32	90267–40X01	.RIVET, BLIND	4					
33	9290L–04600	.WASHER	4					
34	11D–E112B–01	.INSULATOR 2	1					
35	90111–06023	BOLT,HEX. SOCKET BUTTON	2					
36	90480–12581	GROMMET	6					
37	90387–06X36	COLLAR	2					
38	11D–E4648–00	COLLAR 2	4					
39	11D–E4624–00	COVER, EXHAUST	1					
40	11D–E113B–11	INSULATOR 3	1					
41	90387–06X02	COLLAR	2					
42	90111–06X17	BOLT,HEX. SOCKET BUTTON	2					
43	90111–06068	BOLT,HEX. SOCKET BUTTON	4					
44	90167–04X00	SCREW, TAPPING	1					
45	5DS–F8317–00	NUT, EMBLEM	1					
46	11D–E4770–00	STAY, MUFFLER 1	1					
47	5YK–F117B–A0	LABEL, WARNING	1					
48	95817–08014	BOLT, FLANGE	2					
49	90201–086A3	WASHER, PLATE	2					
50	91380–08030	BOLT	2					



11D6300-J130

FIG. 13 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E5100–00	CRANKCASE ASSY	1					
2	99530–12016	.PIN, DOWEL	2					
3	91808–16X00	.PIN, DOWEL	1					
4	93210–07X01	.O-RING	1					
5	91317–06030	BOLT	7					
6	91317–06045	BOLT	2					
7	91317–06055	BOLT	2					
8	91317–06060	BOLT	1					
9	91317–06080	BOLT	1					
10	91317–06090	BOLT	1					
11	90462–07X00	CLAMP	1					
12	11D–E5492–01	COVER	1					
13	5YK–E1166–00	PIPE, BREATHER 1	1					
14	90467–14015	CLIP	1					
15	90467–14015	CLIP	1					
16	5VK–E5383–00	PLATE, BEARING COVER	1					
17	91317–06016	BOLT	3					
18	99530–14016	PIN, DOWEL	2					





FIG. 14 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–WE541–00	CRANKCASE COVER ASSY 1	1					
2	5VK–E5451–10	GASKET, CRANKCASE COVER 1	1					
3	99530–12016	PIN, DOWEL	2					
4	91317–06035	BOLT	1					
5	91317–06025	BOLT	6					
6	91317–06050	BOLT	1					
7	91317–06050	BOLT	1					
8	93210–13X00	O-RING	2					
9	99530–12016	PIN, DOWEL	2					
10	90340–14X00	PLUG, STRAIGHT SCREW	1					
11	93210–14X00	O-RING	1					
12	90340–36X00	PLUG, STRAIGHT SCREW	1					
13	93210–35X00	O-RING	1					
14	91317–06012	BOLT	1					
15	90462–16X00	CLAMP	1					
16	11D–E5421–00	COVER, CRANKCASE 2	1					
17	5VK–E7466–00	GUIDE, CHAIN	1					
18	91317–06045	BOLT	2					
19	5VK–E5431–00	COVER, CRANKCASE 3	1					
20	5VK–E5462–10	GASKET, CRANKCASE COVER 3	1					
21	99530–12016	PIN, DOWEL	2					
22	91317–06030	BOLT	11					
23	5VK–E5441–01	HOLDER, CLUTCH CABLE	1					
24	93101–14164	OIL SEAL	1					
25	5VK–E5118–00	HOLDER	1					
26	91317–06012	BOLT	2					
27	5VK–E5416–00	COVER, OIL PUMP	1					




11D6300-J140

FIG. 14 CRANKCASE COVER 1


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	11D–E5491–00	PROTECTOR	1					
29	5VK–E5453–10	GASKET	1					
30	91808–16X00	PIN, DOWEL	2					
31	95027–06025	BOLT, FLANGE	7					
32	5VK–WE544–10	GENERATOR COVER ASSY	1					
33	91808–16X00	PIN, DOWEL	1					
34	91317–06035	BOLT	1					
35	91317–06025	BOLT	3					
36	5VK–15455–00	GASKET 1	1					

FIG. 15 STARTER



11D6300-J150


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E5515–00	GEAR 3	1					
2	93310–530C7	BEARING	1					
3	90201–30X01	WASHER, PLATE	1					
4	5VK–E5522–00	SHAFT 2	1					
5	5VK–E5517–00	GEAR, IDLER 2	1					
6	5VK–E5560–00	DAMPER ASSY	1					
7	90201–10X18	WASHER, PLATE	2					
8	5VK–15590–00	STARTER ONE-WAY ASSY	1					
9	91317–08025	BOLT	3					
10	90201–08X18	WASHER, PLATE	3					
11	3SX–H1890–00	MOTOR ASSY	1					
12	5VK–E5511–00	.GEAR, STARTING MOTOR	1					
13	93440–11024	.CIRCLIP	1					
14	5VK–H1801–00	.BRUSH SET	1					
15	5VK–H1847–00	.O-RING	1					
16	5VK–H1850–00	.ARMATURE ASSY	1					
17	5VK–H1809–00	.WASHER KIT	1					
18	5VK–H1844–00	.GASKET	2					
19	5VK–H1871–00	CAP	1					
20	5VK–H182A–00	NUT	2					
21	5VK–H1815–00	CORD, STARTER MOTOR	1					
22	95817–06035	BOLT, FLANGE	2					
23	11D–E5199–00	BRACKET	1					
24	90480–13398	GROMMET	1					



11D6300-J160

FIG. 16 CLUTCH


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E6111–00	GEAR, PRIMARY DRIVE	1					
2	90282–07001	KEY, STRAIGHT	1					
3	90209–20012	WASHER	1					
4	90215–20X00	WASHER, LOCK	1					
5	90170–20274	NUT	1					
6	5VK–E6150–10	PRIMARY DRIVEN GEAR COMP.	1					
7	5VK–E6371–00	BOSS, CLUTCH	1					
8	5VK–E6351–00	PLATE, PRESSURE 1	1					
9	93306–00304	BEARING	1					
10	5VK–E6325–00	PLATE, CLUTCH 2	6					
11	22U–16321–00	PLATE, FRICTION	4					
12	90501–26X00	SPRING, COMPRESSION	5					
13	90119–06105	BOLT, WITH WASHER	5					
14	5VK–E6154–00	PLATE, THRUST 1	1					
15	5VK–16331–00	PLATE, FRICTION 2	1					
16	5VK–E6383–00	SPRING.,CUSHION	1					
17	5VK–E6384–00	PLATE, SEAT	1					
18	5TA–16321–00	PLATE, FRICTION	2					
19	90215–20X01	WASHER, LOCK	1					
20	90170–20327	NUT	1					
21	4XV–16356–01	ROD, PUSH 1	1					
22	5VK–16340–00	PUSH LEVER ASSY	1					
23	90508–16X00	SPRING, TORSION	1					
24	5VK–E6382–00	AXLE, PUSH LEVER	1					
25	90201–08X19	WASHER, PLATE	1					
26	99001–07600	CIRCLIP	1					
27	93317–11096	BEARING	1					



11D6300-J160

FIG. 16 CLUTCH


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	93102–15212	OIL SEAL	1					
29	93315–31502	BEARING	1					
30	90201–10X17	WASHER, PLATE	1					
31	93410–10X00	CIRCLIP	1					



11D6300-J170

FIG. 17 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E7401–10	MAIN AXLE ASSY	1					
2	5VK–E7141–10	GEAR, 4TH PINION (22T)	1					
3	90209–21X00	WASHER	2					
4	93440–25084	CIRCLIP	3					
5	5VK–E7131–10	GEAR, 3RD PINION (20T)	1					
6	5VK–E7151–10	GEAR, 5TH PINION (26T)	1					
7	90387–21002	COLLAR	1					
8	90209–22X00	WASHER	1					
9	90209–21351	WASHER	1					
10	5VK–E7121–10	GEAR, 2ND PINION	1					
11	93306–205XA	BEARING	1					
12	93306–004XL	BEARING	1					
13	5VK–E7402–10	DRIVE AXLE ASSY	1					
14	5VK–E7221–10	GEAR, 2ND WHEEL (26T)	1					
15	90209–26348	WASHER	1					
16	93440–28062	CIRCLIP	1					
17	5VK–E7251–10	GEAR, 5TH WHEEL (20T)	1					
18	5VK–E7231–10	GEAR, 3RD WHEEL (23T)	1					
19	90209–21X00	WASHER	1					
20	93440–25084	CIRCLIP	1					
21	5VK–E7241–10	GEAR, 4TH WHEEL (20T)	1					
22	5VK–E7211–10	GEAR, 1ST WHEEL (30T)	1					
23	90201–208G4	WASHER, PLATE	1					
24	93410–20825	CIRCLIP	1					
25	93306–305X4	BEARING	1					
26	90387–25802	COLLAR	1					
27	93210–22X00	O-RING	1					




11D6300-J170

FIG. 17 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	93102–35368	OIL SEAL	1					
29	5VK–E7471–00	PLATE, COVER	1					
30	90101–06X26	BOLT	2					
31	93306–004XM	BEARING	1					
32	5VK–E7460–10	SPROCKET, DRIVE (13T)	1					
33	90215–21X00	WASHER, LOCK	1					
34	90179–18003	NUT	1					


FIG. 18 SHIFT CAM & FORK



11D6300-J180


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–E8540–10	SHIFT CAM ASSY	1					
2	90501–06X00	.SPRING, COMPRESSION	1					
3	5VK–E8542–00	.POINT, NEUTRAL	1					
4	5VK–E8566–00	.PLATE, SIDE 2	1					
5	90149–05X05	.SCREW	1					
6	5VK–E8501–00	FORK, SHIFT 1	1					
7	5VK–E8502–00	FORK, SHIFT 2	1					
8	5VK–E8503–00	FORK, SHIFT 3	1					
9	5VK–E8144–00	HANGER, SPRING	1					
10	132–16346–00	HOOK, SPRING	1					
11	5JW–18140–00	STOPPER LEVER ASSY	1					
12	5VK–18127–00	STOPPER, SCREW	1					
13	93315–11206	BEARING	2					
14	93102–12106	OIL SEAL (SD 12-22-5 HS)	1					
15	99001–10600	CIRCLIP	1					
16	90201–12X06	WASHER, PLATE	1					
17	93410–17X00	CIRCLIP	1					
18	90201–17X01	WASHER, PLATE	1					
19	90201–12X05	WASHER, PLATE	1					
20	5VK–E8699–00	BOSS 1	1					

FIG. 19 SHIFT SHAFT



11D6300-J190


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–18101–00	SHIFT SHAFT ASSY	1					
2	11D–E8110–00	SHIFT PEDAL ASSY	1					
3	5VK–E8113–00	.COVER, SHIFT PEDAL	1					
4	91317–06020	BOLT	1					



11D6300-J200

FIG. 20 FRAME

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F1110–01–98	FRAME COMP.	1					LGB FOR BMC,SMX
2	5VK–F1756–00	.NET, FILTER	1					
3	90430–22123	.GASKET	1					
4	9581M–08012	BOLT, FLANGE	1					
5	90430–08119	GASKET	1					
6	11D–F1400–00	ENGINE BRACKET COMP.	1					
7	95817–10070	BOLT, FLANGE	4					
8	95607–10200	NUT, U FLANGE	4					
9	11D–F1315–00	STAY, ENGINE 2	1					
10	90105–10212	BOLT, FLANGE	3					
11	5YK–F1399–00	CAP	3					
12	95607–10200	NUT, U FLANGE	3					
13	11D–F1410–00	ENGINE BRACKET COMP.	1					
14	90105–10733	BOLT, FLANGE	1					
15	95607–10200	NUT, U FLANGE	1					
16	30X–22178–00	TENSIONER	1					
17	10V–22178–00	TENSIONER	1					
18	10V–22184–00	BUSH	2					
19	90387–08024	COLLAR	2					
20	90201–082H0	WASHER, PLATE	2					
21	95827–08040	BOLT, FLANGE	2					
22	11D–F1761–00	GAUGE, LEVEL	1					
23	93210–19123	O-RING	1					
24	90467–17800	CLIP	1					
25	90450–20X01	HOSE CLAMP ASSY	1					
26	11D–F1344–00	BRACKET, BATTERY BOX	1					
27	9581M–06012	BOLT, FLANGE	2					




11D6300-J200

FIG. 20 FRAME


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	11D–F1471–00	PROTECTOR, ENGINE	1					
29	90480–12072	GROMMET	2					
30	90387–065J6	COLLAR	2					
31	90154–06061	SCREW, BINDING	2					
32	2J5–21732–00	SEAL 1	2					
33	95817–10035	BOLT, FLANGE	2					
34	95607–10200	NUT, U FLANGE	2					
35	11D–F1494–00	NUT	1					
36	11D–F4183–00	DAMPER, LOCATING 3	2					
37	90464–90X00	CLAMP	2					
38	11D–F118W–10	STOPPER	1					
39	11D–F177M–00	DAMPER, LOCATING 3	1					
40	95807–06010	BOLT, FLANGE	2					
41	90464–10X03	CLAMP	1					

FIG. 21 FENDER



11D6300-J210


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F1511–00–P0	FENDER, FRONT	1					FOR SMX
	11D–F1511–00–P3	FENDER, FRONT	1					FOR BMC
2	90387–065J6	COLLAR	4					
3	90480–12497	GROMMET	4					
4	90154–06061	SCREW, BINDING	2					
5	95024–06025	BOLT, FLG.(SMALL HEAD)	2					
6	90179–06403	NUT	2					
7	11D–F1629–00	GUARD, MUD	1					
8	11D–F177G–00	BOX, BATTERY	1					
9	11D–F174A–01	INSULATOR, SIDE COVER	1					
10	11D–F174T–01	INSULATOR, SIDE COVER 2	1					
11	11D–F177N–00	DAMPER, LOCATING 4	1					
12	11D–F1778–00	DAMPER, LOCATING 1	1					
13	11D–F1779–00	DAMPER, LOCATING 2	4					
14	2VW–F1736–00	NUT,PLATE	2					
15	95807–06016	BOLT, FLANGE	2					
16	95807–06008	BOLT, FLANGE	1					
17	95807–06016	BOLT, FLANGE	2					
18	90387–06202	COLLAR	2					
19	11D–F819R–10	TAG, WARNING	1					



11D6300-J220

FIG. 22 REAR ARM


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F2110–00	REAR ARM COMP.	1					
2	93315–22251	BEARING	2					
3	90380–22111	BUSH, SOLID	2					
4	93106–22019	OIL SEAL (DC 22-28-8)	2					
5	30X–2219X–00	COVER	2					
6	93108–35004	OIL SEAL (35-41-8)	2					
7	11D–F2123–00	BUSH 1	2					
8	4YR–22141–10	SHAFT, PIVOT	1					
9	95604–16200	NUT, U FLANGE	1					
10	90201–16021	WASHER, PLATE	1					
11	93317–21746	BEARING	2					
12	93109–17071	OIL SEAL	2					
13	90387–126Y1	COLLAR	1					
14	11D–F217A–00	ARM, RELAY	1					
15	5JN–F217M–00	ARM 1	2					
16	93317–21746	BEARING	2					
17	93317–31771	BEARING	1					
18	93315–31758	BEARING	2					
19	93109–17071	OIL SEAL	6					
20	90387–126Y1	COLLAR	1					
21	90109–12X00	BOLT	2					
22	90185–12119	NUT, SELF-LOCKING	2					
23	90201–124G9	WASHER, PLATE	2					
24	90101–12002	BOLT	1					
25	95617–12100	NUT, U	1					
26	90387–124V0	COLLAR	1					
27	90201–124G9	WASHER, PLATE	1					



11D6300-J220

FIG. 22 REAR ARM


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	90387–127W0	COLLAR	1					
29	11D–F2151–00	SEAL, GUARD	1					
30	1C3–22969–10	SCREW, 1	4					
31	11D–F1823–00	CLAMP, HOSE	1					
32	95027–06012	BOLT, FLANGE	1					
33	11D–F2311–00	CASE, CHAIN	1					
34	1C3–22969–10	SCREW, 1	3					
35	90269–08066	RIVET	2					



11D6300-J230

FIG. 23 REAR SUSPENSION

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F2210–00	SHOCK ABSORBER ASSY, REAR	1					
2	90105–12028	BOLT, FLANGE	1					
3	95607–12200	NUT, SELF-LOCKING	1					
4	90101–10659	BOLT	1					
5	95607–10200	NUT, U FLANGE	1					
6	90201–101J1	WASHER, PLATE	1					




11D6300-J240

FIG. 24 STEERING


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	93332–00008	BEARING	1					
2	93332–00001	BEARING	1					
3	1W1–23416–00	COVER, BALL RACE 2	1					
4	90179–25615	NUT	2					
5	90202–26142	WASHER, PLATE	1					
6	3YF–23418–00	WASHER, SPECIAL	1					
7	90176–22081	NUT, CROWN	1					
8	90201–220T0	WASHER, PLATE	1					
9	11D–F3430–00	HANDLE CROWN COMP.	1					
10	90105–08154	BOLT, FLANGE	4					
11	1E6–23441–10–35	HOLDER, HANDLE UPPER	2					
12	3AJ–23442–00–35	HOLDER, HANDLE LOWER	2					
13	90201–10141	WASHER, PLATE	4					
14	95607–10200	NUT, U FLANGE	2					
15	90105–08154	BOLT, FLANGE	4					

FIG. 25 FRONT FORK



11D6300-J250


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F3102–00	FRONT FORK ASSY (L.H)	1					
2	11D–F3126–00	.TUBE, OUTER (LEFT)	1					
3	11D–F3108–00	..EMBLEM	1					
4	11D–F3110–00	.INNER TUBE COMP.1	1					
5	3XJ–23171–L0	.METAL, SLIDE 2	1					
6	11D–F3170–00	.CYLINDER COMP., FRONT FORK	1					
7	5VK–F3157–00	..RING, PISTON	1					
8	5VK–F3151–00	.SPRING, REBOUND	1					
9	5VK–F3173–00	.SPINDLE, TAPER	1					(PAIOLI)
10	3XJ–23125–L0	.METAL, SLIDE 1	1					
11	4DA–23145–L0	.OIL SEAL	1					
12	11D–F3146–00	.WASHER, OIL SEAL	1					
13	5VK–F3153–00	.RING, SNAP	1					(PAIOLI)
14	4DA–23144–L0	.SEAL, DUST	1					
15	11D–F3141–00	.SPRING, FRONT FORK	1					
16	11D–F3111–00	.BOLT, CAP	1					
17	4V4–23188–L0	.O-RING	1					
18	5JH–F3158–00	.GASKET	1					(PAIOLI)
19	5VK–F3181–00	.BOLT, HEXAGON SOCKET HEAD	1					(PAIOLI)
20	11D–F3118–00	.SPACER	1					
21	5VK–F3149–00	.WASHER, SPRING UPPER	1					(PAIOLI)
22	11D–F3103–00	FRONT FORK ASSY (R.H)	1					
23	11D–F3136–00	.TUBE, OUTER (RIGHT)	1					
24	11D–F3108–00	..EMBLEM	1					
25	11D–F3110–00	.INNER TUBE COMP.1	1					
26	3XJ–23171–L0	.METAL, SLIDE 2	1					
27	11D–F3170–00	.CYLINDER COMP., FRONT FORK	1					



11D6300-J250

FIG. 25 FRONT FORK

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	5VK–F3157–00	..RING, PISTON	1					
29	5VK–F3151–00	.SPRING, REBOUND	1					
30	5VK–F3173–00	.SPINDLE, TAPER	1					(PAIOLI)
31	3XJ–23125–L0	.METAL, SLIDE 1	1					
32	4DA–23145–L0	.OIL SEAL	1					
33	11D–F3146–00	.WASHER, OIL SEAL	1					
34	5VK–F3153–00	.RING, SNAP	1					(PAIOLI)
35	4DA–23144–L0	.SEAL, DUST	1					
36	11D–F3141–00	.SPRING, FRONT FORK	1					
37	11D–F3111–00	.BOLT, CAP	1					
38	4V4–23188–L0	.O-RING	1					
39	5JH–F3158–00	.GASKET	1					(PAIOLI)
40	5VK–F3181–00	.BOLT, HEXAGON SOCKET HEAD	1					(PAIOLI)
41	11D–F3118–00	.SPACER	1					
42	5VK–F3149–00	.WASHER, SPRING UPPER	1					(PAIOLI)
43	5VK–F3128–00	.BOLT, AXLE HOLDER	2					
44	5VK–F3340–00	UNDER BRACKET COMP.	1					
45	5SE–F3394–00	BOLT, SPECIAL	4					(PAIOLI)
46	11D–F3191–00	BOOT	2					
47	11D–F3192–00	BAND	2					
48	98580–04016	.SCREW, PANHEAD (+)	1					
49	11D–F1165–00	HANDLE, STANDING	1					
50	95812–06030	BOLT, FLANGE	4					




11D8300-K260

FIG. 26 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–XF411–30–P0	FUEL TANK COMP.	1					FOR BMC
	11D–XF411–20–P0	FUEL TANK COMP.	1					FOR BMC (ACERBIS)
	11D–XF411–30–P1	FUEL TANK COMP.	1					FOR SMX
	11D–XF411–20–P1	FUEL TANK COMP.	1					FOR SMX (ACERBIS)
2	11D–F4230–10	.GRAPHIC SET 1	1					FOR SMX
	11D–F4240–10	.GRAPHIC SET	1					FOR BMC
3	11D–13907–01	FUEL PUMP COMP.	1					
4	56B–F4491–10	BRACKET, FUEL PUMP	1					
5	5JW–24486–00	O-RING	1					
6	93210–92X01	O-RING	1					
7	93211–04X00	O-RING	1					
8	91317–06016	BOLT	6					
9	5JJ–24602–01	CAP ASSY	1					
10	90110–05112	BOLT, HEXAGON SOCKET HEAD	3					
11	91317–05010	BOLT	1					
12	11D–F4181–00	DAMPER, LOCATING 1	4					
13	11D–F412G–00	COLLAR	2					
14	90467–09006	CLIP	2					
15	11D–F4243–00	ROD 1	2					
16	11D–F4115–00	STAY, FUEL TANK 1	1					
17	95027–06014	BOLT, FLANGE	3					
18	11D–F4116–00	STAY, FUEL TANK 2	1					
19	95027–06014	BOLT, FLANGE	3					
20	11D–F4717–00	BOLT, SEAT FITTING	1					
21	5YK–F4478–00	JOINT	2					
22	11D–F4141–00	PROTECTOR, FUEL TANK	1					
23	11D–F1568–00	LABEL, WARNING	1					


FIG. 26 FUEL TANK




11D8300-K260

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
24	4SU–F415E–00	LABEL, CAUTION	1					
25	11D–F413B–00	EMBLEM	2					
26	11D–F4182–00	DAMPER, LOCATING 2	2					
27	90387–087L3	COLLAR	2					
28	90201–08M03	WASHER, PLATE	2					
29	11D–F4192–00	BRACKET, FUEL TANK 2	1					
30	95817–08040	BOLT, FLANGE	2					
31	11D–F4318–00	PIPE, OVERFLOW	2					
32	5BR–F1335–00	CLAMP, WIRE HARNESS 1	2					215X7.0
33	11D–F137W–00	SCOOP, AIR 1	1					
34	11D–F836U–00	DAMPER, LOCATING 2	1					
35	90111–06X19	BOLT,HEX. SOCKET BUTTON	4					
36	90201–06X28	WASHER, PLATE	4					
37	11D–F137X–00	SCOOP, AIR 2	1					
38	11D–F836U–00	DAMPER, LOCATING 2	1					
39	90111–06X19	BOLT,HEX. SOCKET BUTTON	4					
40	90201–06X28	WASHER, PLATE	4					
41	11D–F8100–00	TOOL KIT	1					
42	11D–F8170–00	HOLDER, TOOL	1					
43	5YK–13971–00	PIPE, FUEL 1	1					
44	90464–16005	CLAMP	1					
45	11D–F8187–00	GROMMET	4					
46	90202–08X01	WASHER, PLATE	4					

FIG. 27 SEAT




REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F4770–10	SEMI-DOUBLE SEAT ASSY	1					FOR BMC
	11D–F4770–20	SEMI-DOUBLE SEAT ASSY	1					FOR SMX
2	11D–F4731–10	.COVER, SEAT	1					YELLOW SEWING
	11D–F4731–20	.COVER, SEAT	1					RED SEWING
3	5YK–F4741–00	.PAD, SEAT	6					
4	5AD–F4780–00	SEAT LOCK ASSY	1					
5	11D–F175H–00	STAY, LOCK	1					
6	90105–05016	BOLT, FLANGE	2					
7	92017–06020	BOLT, BUTTON HEAD	2					
8	90201–06X04	WASHER, PLATE	2					
9	90183–05812	NUT, SPRING	2					
10	11D–F478E–00	CABLE, SEAT LOCK	1					
11	2TV–W2470–00	ROTOR SET	1					
12	92017–06014	BOLT, BUTTON HEAD	2					
13	90338–05008	PLUG	1					
14	11D–F471K–00	COVER, TAIL 1	1					
15	11D–F176B–00	TUNING FORK MARK	1					
16	90111–06X19	BOLT,HEX. SOCKET BUTTON	2					
17	90387–06X01	COLLAR	2					
18	95602–06200	NUT, SELF-LOCKING	2					
19	11D–F474A–00	ASSIST, GRIP	1					
20	11D–F474W–00	ASSIST,GRIP 2	1					
21	95817–08030	BOLT, FLANGE	4					
22	11D–F4481–00	PLUG	4					
23	11D–F4845–01	COVER 1	1					
24	11D–F4846–01	COVER 2	1					
25	97707–40010	SCREW, TAPPING	2					



11D6300-J270

FIG. 27 SEAT

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
26	11D–F4844–00	COVER 3	1					
27	97707–40014	SCREW, TAPPING	2					
28	11D–F483H–00	BAND	1					
29	56P–F8199–E0	MANUAL,OWNER'S	1					UR ENGLISH
	56P–F8199–F0	MANUAL,OWNER'S	1					UR FRENCH
	56P–F8199–G0	MANUAL,OWNER'S	1					UR GERMAN
	56P–F8199–H0	MANUAL,OWNER'S	1					UR ITALIAN
	56P–F8199–S0	MANUAL,OWNER'S	1					UR SPANISH
	56P–F819D–D0	MANUAL,OWNER'S	1					UR DUTCH
	56P–F819D–P0	MANUAL,OWNER'S	1					UR PORTUGUESE




11D6300-J280

FIG. 28 FRONT WHEEL


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F5111–00	HUB, FRONT	1					
2	11D–F5117–00	SPACER, BEARING	1					
3	93306–203XN	BEARING	2					
4	93106–23002	OIL SEAL	2					
5	94418–21X00	RIM (1.85-21)	1					
6	11D–F5104–01	SPOKE SET, FRONT	1					
7	94109–21800	TIRE (90/90-21M/C 54S)	1					METZELER TOURANCE
	94109–21801	TIRE (90/90-21M/C 54T)	1					MICHELIN SIRAC
8	*	TUBE (21)	1					LM UR
	*	TUBE	1					LM UR
9	*	BAND, RIM (21)	1					LM UR
	*	BAND, RIM (1.60-21)	1					LM UR MICHELIN
10	3HT–25398–00	BALANCER, WHEEL (15G)	1					
11	5VK–F5186–00	COLLAR, WHEEL	1					
12	5VK–25181–00	AXLE, WHEEL	1					
13	5VK–F5183–00	COLLAR, WHEEL	1					

FIG. 29 FRONT BRAKE



11D6300-J290

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F580T–00	CALIPER ASSY (LEFT)	1					
2	11D–F5811–00	.PAD, CALIPER 2	1					
3	5D7–F5924–00	.PIN, PAD	1					
4	5D7–F5824–10	.SCREW, BLEED	1					(BREMBO)
5	5DS–F5825–00	.CAP	1					(BREMBO)
6	5DS–F5919–00	.SUPPORT, PAD	1					(BREMBO)
7	5DS–F5917–00	.BOOT, CALIPER	1					(BREMBO)
8	11D–F580U–00	CALIPER ASSY (RIGHT)	1					
9	11D–F5811–00	.PAD, CALIPER 2	1					
10	5D7–F5924–00	.PIN, PAD	1					
11	5D7–F5824–10	.SCREW, BLEED	1					(BREMBO)
12	5DS–F5825–00	.CAP	1					(BREMBO)
13	5DS–F5919–00	.SUPPORT, PAD	1					(BREMBO)
14	5DS–F5917–00	.BOOT, CALIPER	1					(BREMBO)
15	90105–10638	BOLT, FLANGE	4					
16	5VK–F581T–00	DISK BRAKE ASSY	2					
17	90109–064G6	BOLT	12					




11D6300-J310

FIG. 30 REAR BRAKE


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–F580W–00	CALIPER ASSY, REAR 2	1					(BREMBO)
2	5VK–W0046–00	.BRAKE PAD KIT 2	1					(BREMBO)
3	5VK–F5924–10	.PIN, PAD	1					(BREMBO)
4	5VK–F5919–10	.SUPPORT, PAD	1					(BREMBO)
5	5DS–F5825–00	.CAP	1					(BREMBO)
6	5SE–F5824–00	.SCREW, BLEED	1					(BREMBO)
7	5DS–F5917–00	.BOOT, CALIPER	1					(BREMBO)
8	5VK–F582W–00	DISK, REAR BRAKE 2	1					
9	90109–065F3	BOLT	6					

FIG. 31 REAR WHEEL



11D6300-J300


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–25311–00	HUB, REAR	1					
2	90560–17306	SPACER	1					
3	93306–20348	BEARING	2					
4	93106–23002	OIL SEAL	1					
5	5VK–25366–00	CLUTCH, HUB	1					
6	93306–30437	BEARING	1					
7	1VJ–25377–00	COLLAR, WHEEL	1					
8	93106–30029	OIL SEAL	1					
9	90116–10485	BOLT, STUD	6					
10	5VK–25445–01	SPROCKET, DRIVEN (45T)	1					
11	95607–10200	NUT, U FLANGE	6					
12	5Y1–25364–00	DAMPER	4					
13	5VK–F5304–01	SPOKE SET, REAR	1					
14	94427–17X00	RIM	1					
15	94113–17800	TIRE (130/80-17 M/C 65S)	1					METZELER TOURANCE
	94113–17801	TIRE (130/80-17 M/C 65T)	1					MICHELIN SIRAC
16	*	TUBE (21)	1					LM UR
	*	TUBE	1					LM UR
17	*	BAND, RIM (2.15-18)	1					LM UR MICHELIN
	*	BAND, RIM (21)	1					LM UR
18	3HT–25398–00	BALANCER, WHEEL (15G)	1					
19	9456X–08110	CHAIN (520ZRA -110L)	1					
20	10S–25381–00	AXLE, WHEEL	1					
21	10S–F5388–00	PULLER, CHAIN 1	1					
22	10S–F5389–00	PULLER, CHAIN 2	1					
23	90101–08777	BOLT	2					
24	95707–08500	NUT, FLANGE	2					



11D6300-J300

FIG. 31 REAR WHEEL

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
25	90387–17801	COLLAR	1					
26	90387–17802	COLLAR	1					
27	95604–16200	NUT, U FLANGE	1					




11D6300-J320

FIG. 32 STEERING HANDLE & CABLE


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F6111–00	HANDLEBAR	1					
2	4YR–26240–02	GRIP ASSY	1					
3	4YR–26241–02	GRIP (LEFT)	1					
4	11D–F6246–00	END, GRIP	2					
5	5VK–F6311–00	CABLE, THROTTLE 1	1					
6	5VK–F6312–00	CABLE, THROTTLE 2	1					
7	1E6–26342–00	BOOT, CABLE	1					
8	5VK–F6335–00	CABLE, CLUTCH	1					
9	5VK–F6280–00	REAR VIEW MIRROR ASSY (LEFT)	1					
10	5VK–F6290–00	REAR VIEW MIRROR ASSY (RIGHT)	1					

FIG. 33 FRONT MASTER CYLINDER



11D6300-J330

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5PS–W2587–00	MASTER CYLINDER SUB ASSY	1					
2	5VS–W0041–00	.CYLINDER KIT, MASTER	1					
3	5VS–25852–00	.CAP, RESERVOIR	1					
4	5VS–25855–00	.BUSH,DIAPHRAGM	1					
5	20S–25854–00	.DIAPHRAGM, RESERVOIR	1					
6	5VS–2589H–00	.SCREW	2					
7	5VS–2589F–00	BOLT, LEVER	1					
8	95617–06100	NUT, U	1					
9	5VS–83922–00	LEVER 2	1					
10	5VS–26332–00	BOLT	2					
11	5VS–25867–00	BRACKET, MASTER CYLINDER	1					
12	4HM–83980–00	FRONT STOP SWITCH ASSY	1					
13	98502–04012	SCREW, PAN HEAD	1					
14	92902–04100	WASHER, SPRING	1					
15	92902–04600	WASHER, PLATE	1					
16	11D–F5872–00	HOSE, BRAKE 1	1					
17	90401–10X03	BOLT, UNION	3					
18	90201–10X07	WASHER, PLATE	6					
19	95024–06012	BOLT, FLG.(SMALL HEAD)	2					




11D6300-J340


FIG. 34 STAND & FOOTREST

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F7311–00	STAND, SIDE	1					
2	11D–F7321–00	BRACKET, SIDE STAND	1					
3	11D–F7313–00	COLLAR	1					
4	90105–10X16	BOLT, FLANGE	1					
5	90506–25X01	SPRING, TENSION	1					
6	90201–10X21	WASHER, PLATE	1					
7	9561M–10100	NUT, U	1					
8	90110–10191	BOLT, HEXAGON SOCKET HEAD	2					
9	3LD–27411–01	FOOTREST 1	1					
10	3LD–27413–00	COVER, FOOTREST	1					
11	91317–06010	BOLT	1					
12	90508–28777	SPRING, TORSION	1					
13	90240–10101	PIN, CLEVIS	1					
14	91401–25020	PIN, COTTER	1					
15	11D–F7452–00	BRACKET, FOOTREST 1	1					
16	3LD–27421–01	FOOTREST 2	1					
17	3LD–27413–00	COVER, FOOTREST	1					
18	91317–06010	BOLT	1					
19	90508–28777	SPRING, TORSION	1					
20	90240–10101	PIN, CLEVIS	1					
21	91401–25020	PIN, COTTER	1					
22	11D–F7452–00	BRACKET, FOOTREST 1	1					
23	90105–08053	BOLT, FLANGE	2					
24	95607–08200	NUT, SELF-LOCKING	2					
25	11D–F741L–01	BRACKET 4	1					
26	11D–F743A–00	BAR, REAR FOOTREST	1					
27	1B9–F7454–00	COVER, FOOTREST	1					

FIG. 34 STAND & FOOTREST




REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	90157–05079	SCREW, PAN HEAD	2					
29	90501–15001	SPRING, COMPRESSION	1					
30	93501–04011	BALL	1					
31	5JJ–27437–01	WASHER, SPECIAL	1					
32	95817–06040	BOLT, FLANGE	1					
33	90387–06014	COLLAR	1					
34	95604–06200	NUT, U FLANGE	1					
35	90110–08221	BOLT, HEXAGON SOCKET HEAD	2					
36	11D–F742L–01	BRACKET 5	1					
37	11D–F743G–00	BAR, REAR FOOTREST 2	1					
38	1B9–F7454–00	COVER, FOOTREST	1					
39	90157–05079	SCREW, PAN HEAD	2					
40	90501–15001	SPRING, COMPRESSION	1					
41	93501–04011	BALL	1					
42	5JJ–27437–01	WASHER, SPECIAL	1					
43	95817–06040	BOLT, FLANGE	1					
44	90387–06014	COLLAR	1					
45	95604–06200	NUT, U FLANGE	1					
46	90110–08221	BOLT, HEXAGON SOCKET HEAD	2					



11D6300-J350

FIG. 35 REAR MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F7211–00	PEDAL, BRAKE	1					
2	11D–F7216–00	SPRING, RETURN	1					
3	5YK–F7213–00	COLLAR	1					
4	93210–15414	O-RING	2					
5	92017–10045	BOLT, BUTTON HEAD	1					
6	90201–100L3	WASHER, PLATE	1					
7	5VK–2583V–00	RR. MASTER CYLINDER ASSY.	1					
8	3BN–W0042–50	.CYLINDER KIT, MASTER	1					
9	93210–15620	.O-RING	1					
10	2VN–25866–00	.CIRCLIP	1					
11	4ML–2582A–50	.JOINT	1					
12	2YK–27222–00	.JOINT	1					
13	4SS–27218–00	.NUT	2					
14	3KW–27234–00	.PIN, BRAKE ROD	1					
15	5JJ–25894–01	TANK, RESERVOIR	1					
16	3XP–25852–50	CAP, RESERVOIR	1					
17	2VN–25854–00	DIAPHRAGM, RESERVOIR	1					
18	2VN–25855–00	BUSH,DIAPHRAGM	1					
19	11D–25895–00	HOSE, RESERVOIR	1					
20	90467–12085	CLIP	2					
21	90119–06044	BOLT, WITH WASHER	1					
22	90240–08124	PIN, CLEVIS	1					
23	90201–08083	WASHER, PLATE	1					
24	91401–20012	PIN, COTTER	1					
25	11D–F7446–00	PLATE 2	1					
26	92014–08025	BOLT, BUTTON HEAD	2					
27	11D–H2530–00	STOP SWITCH ASSY	1					




11D6300-J350

FIG. 35 REAR MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	11D–F5873–00	HOSE, BRAKE 2	1					
29	90401–10X03	BOLT, UNION	1					
30	90201–10X07	WASHER, PLATE	4					


FIG. 36 COWLING



11D6300-J360


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–F8351–00–P0	BODY, COWLING	1					FOR SMX
	11D–F8351–00–P3	BODY, COWLING	1					FOR BMC
2	97017–06025	BOLT	2					
3	90387–06X02	COLLAR	2					
4	2VW–F1736–00	NUT,PLATE	2					
5	11D–F8381–10	WINDSHIELD	1					
6	11D–F836B–00	TUNING FORK MARK	1					
7	90179–05523	NUT	6					
8	90150–05024	SCREW, ROUND HEAD	6					
9	11D–F842M–00	COVER 1	1					
10	11D–F836L–00	PANEL, INNER 2	1					
11	11D–F842N–00	COVER 2	1					
12	11D–F836M–00	PANEL, INNER 3	1					
13	90179–06520	NUT	4					
14	11D–F836U–00	DAMPER, LOCATING 2	6					
15	90111–06X20	BOLT,HEX. SOCKET BUTTON	4					
16	90387–06X09	COLLAR	4					
17	95817–06050	BOLT, FLANGE	1					

FIG. 37 GENERATOR



11D6300-J370

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	5VK–81410–00	STATOR ASSY	1					
2	5VK–81450–10	ROTOR ASSY	1					
3	92017–06030	BOLT, BUTTON HEAD	3					
4	91317–05014	BOLT	2					
5	90201–05X08	WASHER, PLATE	2					




11D6300-J380

FIG. 38 FLASHER LIGHT

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–H3310–10	FRONT FLASHER LIGHT ASSY 1	1					
2	22B–H3312–00	.LENS, FLASHER	1					
3	5VK–H3311–00	.BULB, FLASHER (12V/10W)	1					
4	5D7–H3333–00	.SCREW, LENS FITTING	1					
5	11D–H3320–10	FRONT FLASHER LIGHT ASSY 2	1					
6	22B–H3322–00	.LENS, FLASHER 2	1					
7	5VK–H3311–00	.BULB, FLASHER (12V/10W)	1					
8	5D7–H3333–00	.SCREW, LENS FITTING	1					
9	9131M–06020	BOLT	2					
10	90185–06837	NUT, SELF-LOCKING	2					
11	90387–06X01	COLLAR	2					
12	11D–H3330–11	REAR FLASHER LIGHT ASSY 1	1					
13	22B–H3322–00	.LENS, FLASHER 2	1					
14	5VK–H3311–00	.BULB, FLASHER (12V/10W)	1					
15	5D7–H3333–00	.SCREW, LENS FITTING	1					
16	11D–H3340–11	REAR FLASHER LIGHT ASSY 2	1					
17	22B–H3312–00	.LENS, FLASHER	1					
18	5VK–H3311–00	.BULB, FLASHER (12V/10W)	1					
19	5D7–H3333–00	.SCREW, LENS FITTING	1					
20	9131M–06020	BOLT	2					
21	90185–06837	NUT, SELF-LOCKING	2					
22	90387–06M31	COLLAR	2					


FIG. 39 METER



11D6300-J390

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–H3500–02	METER ASSY	1					
2	5CH–H3523–00	DAMPER	3					
3	90164–05014	SCREW, TAPPING	3					
4	2VW–F1736–00	NUT,PLATE	2					
5	11D–F8356–00	STAY 1	1					
6	95817–08045	BOLT, FLANGE	2					
7	95607–08200	NUT, SELF-LOCKING	2					
8	90480–01558	GROMMET	2					
9	11D–F836K–00	PANEL, INNER 1	1					
10	90111–06X17	BOLT,HEX. SOCKET BUTTON	2					
11	90387–06X38	COLLAR	2					


FIG. 40 HEADLIGHT




11D6300-J400

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–H410A–10	HEADLIGHT UNIT COMP.	1					
2	5JN–H4352–00	.GROMMET	2					
3	5B2–H4314–00	BULB, HEADLIGHT (H7, 12V-55W)	2					
4	*	BULB (12V-3W)	2					LM
5	11D–H4312–00	CORD ASSY	1					
6	90480–14023	GROMMET	2					
7	90387–068L3	COLLAR	5					
8	95817–06035	BOLT, FLANGE	4					
9	9290M–06200	WASHER	2					

FIG. 41 TAILLIGHT




REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	56P–H4710–00	TAILLIGHT UNIT ASSY	1					
2	97707–40012	SCREW, TAPPING	4					
3	11D–F1685–00	BRACKET, LICENSE	1					
4	90480–11006	GROMMET	4					
5	90201–06X14	WASHER, PLATE	4					
6	90387–06X41	COLLAR	7					
7	90387–06X42	COLLAR	4					
8	47X–21736–01	NUT,PLATE	2					
9	92017–06020	BOLT, BUTTON HEAD	2					
10	9201L–06025	BOLT, BUTTON HEAD	2					
11	11D–H4745–01	LICENCE LIGHT UNIT ASSY	1					
12	5YK–H4749–00	.BODY, LICENCE LIGHT	1					
13	5YK–H4741–00	.BASE, LICENCE LIGHT	1					
14	9770L–30110	.SCREW, TAPPING	2					
15	*	.BULB (12V-5W)	1					
16	11D–H4547–01	.CORD, LICENCE LIGHT	1					
17	9570L–05300	NUT, FLANGE	2					
18	9290L–05200	WASHER	2					
19	11D–H2589–01	PROTECTER, WIRE HARNESS	1					
20	11D–F1670–01	REINF. COMP.	1					
21	9201L–06014	BOLT, BUTTON HEAD	3					
22	97707–40020	SCREW, TAPPING	4					
23	5YK–H5130–00	REAR REFLECTOR ASSY	1					
24	92907–04200	WASHER	2					
25	9570L–04300	NUT, FLANGE	2					
26	3SH–H4551–00	BRACKET, LICENCE	1					
27	9581M–06016	BOLT, FLANGE	2					



11D6300-J410

FIG. 41 TAILLIGHT


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	90201–06X14	WASHER, PLATE	2					
29	9571L–06300	NUT, FLANGE	2					



11D6300-J420

FIG. 42 HANDLE SWITCH & LEVER


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	11D–H3912–00	LEVER 1	1					
2	11D–H2911–00	HOLDER, LEVER 1	1					
3	11D–H3951–00	BOLT, CABLE ADJUSTING	1					
4	5D7–H3927–00	NUT, ADJUSTING	1					
5	11D–H3945–00	BOLT, LEVER	1					
6	90185–06837	NUT, SELF-LOCKING	1					
7	11D–H3546–00	BOLT	2					
8	11D–H2913–00	HOLDER, LEVER LOWER 1	1					
9	3YX–82917–01	SWITCH	1					
10	98707–03020	SCREW, FLAT HEAD	1					
11	5VK–83969–00	SWITCH, HANDLE 5	1					
12	98507–05030	.SCREW, PAN HEAD	1					
13	98507–05045	.SCREW, PAN HEAD	1					
14	5VK–83975–00	SWITCH, HANDLE 2	1					
15	98507–05055	.SCREW, PAN HEAD	1					
16	92907–05600	.WASHER, PLATE	1					
17	98507–05045	.SCREW, PAN HEAD	1					
18	98507–05020	.SCREW, PAN HEAD	1					
19	11D–H1662–00	COVER, CONNECTER	1					
20	90464–25004	CLAMP	4					



11D8300-K430

FIG. 43 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	90111–06X19	BOLT,HEX. SOCKET BUTTON	2					
2	9570L–06500	NUT, FLANGE	2					
3	4GV–82310–00	IGNITION COIL ASSY	1					
4	9131M–05020	BOLT	2					
5	9290M–05600	WASHER	2					
6	11D–H5991–00	BRACKET, UNIT	1					
7	90387–06202	COLLAR	2					
8	95607–06200	NUT, SELF U-FLANGE	2					
9	5VK–82370–00	PLUG CAP ASSY	1					
10	4XY–81960–00	RECTIFIER & REGULATOR ASSY	1					
11	90201–06072	WASHER, PLATE	2					
12	90480–15363	GROMMET	2					
13	95807–06040	BOLT, FLANGE	2					
14	90387–06042	COLLAR	2					
15	5FL–82100–01	BATTERY ASSY (GT9B-4)	1					
16	11D–F1287–00	BRACKET, REGULATOR	1					
17	5YK–82115–00	WIRE, PLUS LEAD	1					
18	11D–H2116–00	WIRE, MINUS LEAD	1					
19	11D–W8250–10	MAIN SW. IMMOBILIZER KIT	1					
20	11D–8591A–00	.ENGINE CONTROL UNIT ASSY	1					
21	5YK–8255P–00	.IMMOBILIZER. UNIT COMP.	1					
22	5SL–82113–01	.SCREW	2					
23	5SL–82511–08	BLANK KEY	1					AP
24	90109–08195	BOLT	2					
25	11D–H2568–00	COVER, MAIN SWITCH	1					
26	90111–05011	BOLT,HEX. SOCKET BUTTON	2					
27	11D–H2590–01	WIRE HARNESS ASSY	1					




11D8300-K430

FIG. 43 ELECTRICAL 1


REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	5JJ–82151–20	.FUSE (20A-BL)	2					
29	5JJ–82151–30	.FUSE (10A-BL)	6					
30	5JJ–82151–00	.FUSE (7.5A-BL)	2					
31	90464–32X00	CLAMP	11					
32	90464–90X00	CLAMP	15					
33	90464–25004	CLAMP	2					

FIG. 44 ELECTRICAL 2



11D6300-J440

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
1	1AE–82540–00	NEUTRAL SWITCH ASSY	1					
2	93210–29X00	O-RING	1					
3	90110–06122	BOLT, HEXAGON SOCKET HEAD	2					
4	5PS–85790–00	THERMOSENSOR ASSY	1					
5	90430–12X01	GASKET	1					
6	5PS–82380–00	SENSOR, PRESSURE	1					
7	9571L–06300	NUT, FLANGE	2					
8	5VU–85886–00	SENSOR, AIR TEMPRATURE	1					
9	5CA–14435–00	GROMMET	1					
10	11D–83755–00	SENSOR, SPEED	1					
11	4D9–81168–00	.O-RING	1					
12	91317–06014	BOLT	1					
13	4SV–81940–12	STARTER RELAY ASSY	1					
14	1AE–82151–00	.FUSE (30A-BL)	2					
15	95027–06008	BOLT, FLANGE	2					
16	5VK–81950–40	RELAY ASSY	1					
17	5EA–81950–20	RELAY ASSY	2					
18	5EA–81952–00	.HOLDER, RELAY	1					
19	2S5–H2576–00	SENSOR, LEAN ANGLE	1					
20	97707–40025	SCREW, TAPPING	2					
21	90201–047A2	WASHER, PLATE	2					
22	11D–H1953–00	STAY, RELAY	1					
23	4GY–83350–00	FLASHER RELAY ASSY	1					
24	5VK–H3371–00	HORN	1					
25	11D–H3376–00	COVER, HORN	1					
26	9581M–06012	BOLT, FLANGE	1					
27	5VS–82566–61	SWITCH, SIDE STAND	1					



11D6300-J440

FIG. 44 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	11D8					REMARKS
28	92017–05025	BOLT, BUTTON HEAD	2					
29	95607–05200	NUT, U FLANGE	2					
30	9581M–06014	BOLT, FLANGE	2					
31	90387–06202	COLLAR	2					

PART NO.	REF. NO.
4G0–11133–11	1 – 2
5VK–11181–00	1 – 4
214–11198–01	8 – 14
5VK–11311–00	2 – 1
5VK–11351–00	2 – 2
5VK–11400–01	3 – 1
5VK–11401–09	3 – 2
5VK–11422–00	3 – 3
5VK–11603–00	3 – 12
5VK–11631–00	3 – 11
5VK–11633–00	3 – 13
5VK–11651–00	3 – 6
5VK–11681–01	3 – 4
5VK–12111–00	4 – 1
5VK–12113–00	4 – 3
3YF–12116–00	4 – 4
3YF–12117–01	4 – 6
4G0–12118–00	4 – 7
5H0–12119–00	4 – 5
5VK–12121–00	4 – 2
5VK–12146–00	4 – 10
5BP–12159–01	4 – 11
4DW–12213–00	5 – 15
5VK–12280–01	5 – 5
5VK–12284–00	5 – 3
5VK–12290–00	5 – 4
5VK–12410–00	7 – 1
5VK–12421–00	6 – 6
5VK–12422–00	6 – 3
5VK–12428–00	6 – 11
11H–12438–10	6 – 9
5VK–12450–00	6 – 2
5VK–12459–00	6 – 14
5VK–12481–00	6 – 19
583–13113–00	8 – 32
5VK–13160–00	10 – 2
5VK–13161–00	8 – 25
5VK–13171–00	8 – 28
3AJ–13325–00	8 – 5
5LP–13329–00	8 – 2
11D–13405–00	8 – 39
4X7–13440–01	8 – 17
2WK–13447–00	8 – 18
5VK–13464–00	8 – 35
11D–13467–00	8 – 40
5YK–13750–11	10 – 1
5VK–13761–00	10 – 8
11D–13907–01	26 – 3
5YK–13971–00	26 – 43
5PS–14147–00	10 – 9
8CC–14216–10	10 – 5
5CA–14435–00	44 – 9
56B–14503–00	10 – 6
5VK–14531–00	10 – 7
3YF–14613–01	12 – 21
4EL–14714–00	12 – 7
	12 – 12
5VK–14803–00	11 – 6
5VK–14815–00	11 – 2
5VK–14871–02	11 – 1
5VK–15455–00	14 – 36
5VK–15590–00	15 – 8
22U–16321–00	16 – 11
5TA–16321–00	16 – 18
5VK–16331–00	16 – 15
5VK–16340–00	16 – 22
132–16346–00	18 – 10
4XV–16356–01	16 – 21
5VK–18101–00	19 – 1
5VK–18127–00	18 – 12
5JW–18140–00	18 – 11
2J5–21732–00	20 – 32
47X–21736–01	41 – 8
4YR–22141–10	22 – 8
10V–22178–00	20 – 17
30X–22178–00	20 – 16
10V–22184–00	20 – 18
30X–2219X–00	22 – 5
1C3–22969–10	22 – 30
	22 – 34
3XJ–23125–L0	25 – 10
	25 – 31
4DA–23144–L0	25 – 14
	25 – 35
4DA–23145–L0	25 – 11
	25 – 32
3XJ–23171–L0	25 – 5
	25 – 26
4V4–23188–L0	25 – 17
	25 – 38
1W1–23416–00	24 – 3
3YF–23418–00	24 – 6
1E6–23441–10–35	24 – 11
3AJ–23442–00–35	24 – 12
5JW–24486–00	26 – 5
5JJ–24602–01	26 – 9
5VK–25181–00	28 – 12
5VK–25311–00	31 – 1
5Y1–25364–00	31 – 12
5VK–25366–00	31 – 5
1VJ–25377–00	31 – 7
10S–25381–00	31 – 20
3HT–25398–00	28 – 10
	31 – 18
5VK–25445–01	31 – 10
4ML–2582A–50	35 – 11
5VK–2583V–00	35 – 7
5VS–25852–00	33 – 3
3XP–25852–50	35 – 16
20S–25854–00	33 – 5
2VN–25854–00	35 – 17
2VN–25855–00	35 – 18
5VS–25855–00	33 – 4
2VN–25866–00	35 – 10
5VS–25867–00	33 – 11
5JJ–25894–01	35 – 15
11D–25895–00	35 – 19
5VS–2589F–00	33 – 7
5VS–2589H–00	33 – 6
4YR–26240–02	32 – 2
4YR–26241–02	32 – 3
5VS–26332–00	33 – 10
1E6–26342–00	32 – 7
4SS–27218–00	35 – 13
2YK–27222–00	35 – 12
3KW–27234–00	35 – 14
3LD–27411–01	34 – 9
3LD–27413–00	34 – 10
	34 – 17
3LD–27421–01	34 – 16
5JJ–27437–01	34 – 31
	34 – 42
4D9–81168–00	44 – 11
5VK–81410–00	37 – 1
5VK–81450–10	37 – 2
4SV–81940–12	44 – 13
5EA–81950–20	44 – 17
5VK–81950–40	44 – 16
5EA–81952–00	44 – 18
4XY–81960–00	43 – 10
5FL–82100–01	43 – 15
5SL–82113–01	43 – 22
5YK–82115–00	43 – 17
1AE–82151–00	44 – 14
5JJ–82151–00	43 – 30
5JJ–82151–20	43 – 28
5JJ–82151–30	43 – 29
4GV–82310–00	43 – 3
5VK–82370–00	43 – 9
5PS–82380–00	44 – 6
5SL–82511–08	43 – 23
1AE–82540–00	44 – 1
5YK–8255P–00	43 – 21
5VS–82566–61	44 – 27
3YX–82917–01	42 – 9
4GY–83350–00	44 – 23
11D–83755–00	44 – 10
5VS–83922–00	33 – 9
5VK–83969–00	42 – 11
5VK–83975–00	42 – 14
4HM–83980–00	33 – 12
5PS–85790–00	44 – 4
3P6–85885–00	10 – 10
5VU–85886–00	44 – 8
11D–8591A–00	43 – 20
1B9–8592A–00	12 – 5
5VK–E1101–02	1 – 1
11D–E111B–01	12 – 28
5VK–E111F–00	5 – 6
11D–E112B–01	12 – 34
11D–E113B–01	12 – 11
11D–E113B–11	12 – 40
5YK–E1166–00	13 – 13
11D–E1167–00	9 – 15
5VK–E1185–00	1 – 12
5VK–E1186–00	1 – 16
5VK–E1454–00	3 – 18
5VK–E1531–00	3 – 17
5VK–E1536–00	3 – 16
5VK–E2151–00	4 – 8
5VK–E2161–00	4 – 9
5VK–E2170–20	5 – 1
5VK–E2210–00	5 – 13
5VK–E2231–00	5 – 10
5VK–E2241–00	5 – 11
11D–E2405–00	7 – 9
11D–E240J–00	7 – 17
11D–E240K–00	7 – 20
5VK–E2413–00	7 – 2
5VK–E2436–00	6 – 1
5YK–E243A–10	9 – 21
5YK–E244G–00	9 – 22
11D–E2461–01	7 – 8
5VK–E2462–00	7 – 10
56P–E2465–00	7 – 16
5VK–E2469–00	6 – 16
11D–E2498–00	7 – 32
5VK–E2577–10	6 – 22
11D–E2578–00	7 – 5
11D–E2579–00	7 – 25
5B2–E2623–00	7 – 12
11D–E2662–00	7 – 14
5B2–E2671–00	7 – 13
5B2–E2675–00	7 – 11
5VK–E3181–00	8 – 15
5VK–E3300–00	8 – 1
5VK–E3327–00	8 – 8
5VK–E3356–00	8 – 7
5VK–E3415–10	8 – 11
11D–E3542–00	9 – 29
11D–E3545–00	9 – 26
5VK–E3586–10	9 – 1
11D–E4411–00	9 – 3
11D–E441A–00	9 – 4
11D–E441E–00	9 – 5
11D–E4430–00	9 – 10
11D–E443E–00	9 – 12
11D–E4451–00	9 – 9
11D–E4452–00	9 – 7
11D–E4453–00	9 – 6
11D–E4457–00	9 – 11
11D–E4611–00	12 – 1
5YK–E4612–00	12 – 2
11D–E4621–00	12 – 6
11D–E4624–00	12 – 39
11D–E4628–00	12 – 10
11D–E4631–01	12 – 13
11D–E4648–00	12 – 38
11D–E4708–01	12 – 23
11D–E4708–11	12 – 29
11D–E4710–20	12 – 19
5YK–E4714–00	12 – 16
11D–E4715–00	12 – 14
11D–E4718–00	12 – 24
11D–E4728–00	12 – 30
5CH–E4766–00	12 – 18
11D–E4770–00	12 – 46
5YK–E477R–00	12 – 3
5YK–E477T–00	12 – 8
11D–E4787–00	12 – 25
11D–E4798–00	12 – 31
11D–E4881–00	11 – 4
11D–E4882–00	11 – 7
5VK–E5100–00	13 – 1
5VK–E5118–00	14 – 25
11D–E5199–00	15 – 23
11D–E5371–11	9 – 31
5VK–E5383–00	13 – 16
5VK–E5416–00	14 – 27
11D–E5421–00	14 – 16
5VK–E5431–00	14 – 19
5VK–E5441–01	14 – 23
5VK–E5451–10	14 – 2
5VK–E5453–10	14 – 29
5VK–E5462–10	14 – 20
11D–E5491–00	14 – 28
11D–E5492–01	13 – 12
5VK–E5511–00	15 – 12
5VK–E5515–00	15 – 1
5VK–E5517–00	15 – 5
5VK–E5522–00	15 – 4
5VK–E5560–00	15 – 6
5VK–E6111–00	16 – 1
5VK–E6150–10	16 – 6
5VK–E6154–00	16 – 14
5VK–E6325–00	16 – 10
5VK–E6351–00	16 – 8
5VK–E6371–00	16 – 7
5VK–E6382–00	16 – 24
5VK–E6383–00	16 – 16
5VK–E6384–00	16 – 17
5VK–E7121–10	17 – 10
5VK–E7131–10	17 – 5
5VK–E7141–10	17 – 2
5VK–E7151–10	17 – 6
5VK–E7211–10	17 – 22
5VK–E7221–10	17 – 14
5VK–E7231–10	17 – 18
5VK–E7241–10	17 – 21
5VK–E7251–10	17 – 17
5VK–E7401–10	17 – 1
5VK–E7402–10	17 – 13
5VK–E7460–10	17 – 32
5VK–E7466–00	14 – 17
5VK–E7471–00	17 – 29
11D–E8110–00	19 – 2
5VK–E8113–00	19 – 3
5VK–E8144–00	18 – 9

PART NO.	REF. NO.
5VK–E8501–00	18 – 6
5VK–E8502–00	18 – 7
5VK–E8503–00	18 – 8
5VK–E8540–10	18 – 1
5VK–E8542–00	18 – 3
5VK–E8566–00	18 – 4
5VK–E8699–00	18 – 20
11D–F1110–01–98	20 – 1
11D–F1165–00	25 – 49
5YK–F117B–A0	12 – 47
11D–F118W–10	20 – 38
11D–F1287–00	43 – 16
11D–F1315–00	20 – 9
5BR–F1335–00	26 – 32
11D–F1344–00	20 – 26
11D–F137W–00	26 – 33
11D–F137X–00	26 – 37
5YK–F1399–00	20 – 11
11D–F1400–00	20 – 6
11D–F1410–00	20 – 13
11D–F1471–00	20 – 28
11D–F1494–00	20 – 35
11D–F1511–00–P0	21 – 1
11D–F1511–00–P3	21 – 1
11D–F1568–00	26 – 23
11D–F1629–00	21 – 7
11D–F1670–01	41 – 20
11D–F1685–00	41 – 3
2VW–F1736–00	7 – 35
	12 – 20
	21 – 14
	36 – 4
	39 – 4
11D–F174A–01	21 – 9
11D–F174T–01	21 – 10
5VK–F1756–00	20 – 2
11D–F175H–00	27 – 5
11D–F1761–00	20 – 22
11D–F176B–00	27 – 15
5DS–F1771–00	7 – 40
11D–F1778–00	21 – 12
11D–F1779–00	21 – 13
11D–F177G–00	21 – 8
11D–F177M–00	20 – 39
11D–F177N–00	21 – 11
11D–F1823–00	22 – 31
11D–F1871–00	7 – 36
11D–F1873–00	7 – 41

PART NO.	REF. NO.
11D–F2110–00	22 – 1
11D–F2123–00	22 – 7
11D–F2151–00	22 – 29
11D–F217A–00	22 – 14
5JN–F217M–00	22 – 15
11D–F2210–00	23 – 1
11D–F2311–00	22 – 33
11D–F3102–00	25 – 1
11D–F3103–00	25 – 22
11D–F3108–00	25 – 3
	25 – 24
11D–F3110–00	25 – 4
	25 – 25
11D–F3111–00	25 – 16
	25 – 37
11D–F3118–00	25 – 20
	25 – 41
11D–F3126–00	25 – 2
5VK–F3128–00	25 – 43
11D–F3136–00	25 – 23
11D–F3141–00	25 – 15
	25 – 36
11D–F3146–00	25 – 12
	25 – 33
5VK–F3149–00	25 – 21
	25 – 42
5VK–F3151–00	25 – 8
	25 – 29
5VK–F3153–00	25 – 13
	25 – 34
5VK–F3157–00	25 – 7
	25 – 28
5JH–F3158–00	25 – 18
	25 – 39
11D–F3170–00	25 – 6
	25 – 27
5VK–F3173–00	25 – 9
	25 – 30
5VK–F3181–00	25 – 19
	25 – 40
11D–F3191–00	25 – 46
11D–F3192–00	25 – 47
5VK–F3340–00	25 – 44
5SE–F3394–00	25 – 45
11D–F3430–00	24 – 9
11D–F4115–00	26 – 16
11D–F4116–00	26 – 18
11D–F412G–00	26 – 13

PART NO.	REF. NO.
11D–F413B–00	26 – 25
11D–F4141–00	26 – 22
4SU–F415E–00	26 – 24
11D–F4181–00	26 – 12
11D–F4182–00	26 – 26
11D–F4183–00	20 – 36
11D–F4192–00	26 – 29
11D–F4230–10	26 – 2
11D–F4240–10	26 – 2
11D–F4243–00	26 – 15
11D–F4318–00	26 – 31
5YK–F4478–00	26 – 21
11D–F4481–00	27 – 22
56B–F4491–10	26 – 4
11D–F4717–00	26 – 20
11D–F471K–00	27 – 14
11D–F4731–10	27 – 2
11D–F4731–20	27 – 2
5YK–F4741–00	27 – 3
11D–F474A–00	27 – 19
11D–F474W–00	27 – 20
11D–F4770–10	27 – 1
11D–F4770–20	27 – 1
5AD–F4780–00	27 – 4
11D–F478E–00	27 – 10
11D–F483H–00	27 – 28
11D–F4844–00	27 – 26
11D–F4845–01	27 – 23
11D–F4846–01	27 – 24
11D–F5104–01	28 – 6
11D–F5111–00	28 – 1
11D–F5117–00	28 – 2
5VK–F5183–00	28 – 13
5VK–F5186–00	28 – 11
5VK–F5304–01	31 – 13
10S–F5388–00	31 – 21
10S–F5389–00	31 – 22
11D–F580T–00	29 – 1
11D–F580U–00	29 – 8
5VK–F580W–00	30 – 1
11D–F5811–00	29 – 2
	29 – 9
5VK–F581T–00	29 – 16
5SE–F5824–00	30 – 6
5D7–F5824–10	29 – 4
	29 – 11
5DS–F5825–00	29 – 5
	29 – 12

PART NO.	REF. NO.
5DS–F5825–00	30 – 5
5VK–F582W–00	30 – 8
11D–F5872–00	33 – 16
11D–F5873–00	35 – 28
5DS–F5917–00	29 – 7
	29 – 14
	30 – 7
5DS–F5919–00	29 – 6
	29 – 13
5VK–F5919–10	30 – 4
5D7–F5924–00	29 – 3
	29 – 10
5VK–F5924–10	30 – 3
11D–F6111–00	32 – 1
11D–F6246–00	32 – 4
5VK–F6280–00	32 – 9
5VK–F6290–00	32 – 10
5VK–F6311–00	32 – 5
5VK–F6312–00	32 – 6
5VK–F6335–00	32 – 8
11D–F7211–00	35 – 1
5YK–F7213–00	35 – 3
11D–F7216–00	35 – 2
11D–F7311–00	34 – 1
11D–F7313–00	34 – 3
11D–F7321–00	34 – 2
11D–F741L–01	34 – 25
11D–F742L–01	34 – 36
11D–F743A–00	34 – 26
11D–F743G–00	34 – 37
11D–F7446–00	35 – 25
11D–F7452–00	34 – 15
	34 – 22
1B9–F7454–00	34 – 27
	34 – 38
11D–F8100–00	26 – 41
11D–F8170–00	26 – 42
11D–F8187–00	26 – 45
56P–F8199–E0	27 – 29
56P–F8199–F0	27 – 29
56P–F8199–G0	27 – 29
56P–F8199–H0	27 – 29
56P–F8199–S0	27 – 29
56P–F819D–D0	27 – 29
56P–F819D–P0	27 – 29
11D–F819R–10	21 – 19
5DS–F8317–00	12 – 45
11D–F8345–00	7 – 15

PART NO.	REF. NO.
11D–F8351–00–P0	36 – 1
11D–F8351–00–P3	36 – 1
11D–F8356–00	39 – 5
11D–F836B–00	36 – 6
11D–F836K–00	39 – 9
11D–F836L–00	36 – 10
11D–F836M–00	36 – 12
11D–F836U–00	26 – 34
	26 – 38
	36 – 14
11D–F8381–10	36 – 5
11D–F842M–00	36 – 9
11D–F842N–00	36 – 11
11D–H1662–00	42 – 19
5VK–H1801–00	15 – 14
5VK–H1809–00	15 – 17
5VK–H1815–00	15 – 21
5VK–H182A–00	15 – 20
5VK–H1844–00	15 – 18
5VK–H1847–00	15 – 15
5VK–H1850–00	15 – 16
5VK–H1871–00	15 – 19
3SX–H1890–00	15 – 11
11D–H1953–00	44 – 22
11D–H2116–00	43 – 18
11D–H2530–00	35 – 27
11D–H2568–00	43 – 25
2S5–H2576–00	44 – 19
11D–H2589–01	41 – 19
11D–H2590–01	43 – 27
11D–H2911–00	42 – 2
11D–H2913–00	42 – 8
11D–H3310–10	38 – 1
5VK–H3311–00	38 – 3
	38 – 7
	38 – 14
	38 – 18
22B–H3312–00	38 – 2
	38 – 17
11D–H3320–10	38 – 5
22B–H3322–00	38 – 6
	38 – 13
11D–H3330–11	38 – 12
5D7–H3333–00	38 – 4
	38 – 8
	38 – 15
	38 – 19
11D–H3340–11	38 – 16

PART NO.	REF. NO.
5VK–H3371–00	44 – 24
11D–H3376–00	44 – 25
11D–H3500–02	39 – 1
5CH–H3523–00	39 – 2
11D–H3546–00	42 – 7
11D–H3912–00	42 – 1
5D7–H3927–00	42 – 4
11D–H3945–00	42 – 5
11D–H3951–00	42 – 3
11D–H410A–10	40 – 1
11D–H4312–00	40 – 5
5B2–H4314–00	40 – 3
5JN–H4352–00	40 – 2
11D–H4547–01	41 – 16
3SH–H4551–00	41 – 26
56P–H4710–00	41 – 1
5YK–H4741–00	41 – 13
11D–H4745–01	41 – 11
5YK–H4749–00	41 – 12
5YK–H5130–00	41 – 23
11D–H5991–00	43 – 6
5VS–W0041–00	33 – 2
3BN–W0042–50	35 – 8
5VK–W0046–00	30 – 2
2TV–W2470–00	27 – 11
5PS–W2587–00	33 – 1
11D–W8250–10	43 – 19
5VK–WE343–00	8 – 10
5VK–WE541–00	14 – 1
5VK–WE544–10	14 – 32
11D–XF411–20–P0	26 – 1
11D–XF411–20–P1	26 – 1
11D–XF411–30–P0	26 – 1
11D–XF411–30–P1	26 – 1
90101–06X26	17 – 30
90101–08777	31 – 23
90101–10659	23 – 4
90101–12002	22 – 24
90105–05016	27 – 6
90105–07004	5 – 8
90105–08053	34 – 23
90105–08154	24 – 10
	24 – 15
90105–08X20	12 – 4
	12 – 9
	12 – 15
90105–09002	1 – 5
90105–09003	1 – 7

PART NO.	REF. NO.
90105–09004	1 – 6
90105–10077	2 – 4
90105–10078	2 – 3
90105–10212	20 – 10
90105–10638	29 – 15
90105–10733	20 – 14
90105–10X16	34 – 4
90105–12028	23 – 2
90109–06419	8 – 21
90109–064G6	29 – 17
90109–065F3	30 – 9
90109–08195	43 – 24
90109–12X00	22 – 21
90110–05112	26 – 10
90110–06122	44 – 3
90110–06202	7 – 37
90110–08221	34 – 35
	34 – 46
90110–10191	34 – 8
90111–05011	43 – 26
90111–06023	12 – 35
90111–06051	9 – 32
90111–06068	12 – 43
90111–06X17	7 – 22
	12 – 42
	39 – 10
90111–06X19	7 – 18
	7 – 21
	7 – 33
	26 – 35
	26 – 39
	27 – 16
	43 – 1
90111–06X20	7 – 30
	36 – 15
90116–10485	31 – 9
90119–06044	35 – 21
90119–06105	16 – 13
90119–06X05	5 – 12
90149–05110	8 – 23
90149–05X05	18 – 5
90150–05024	36 – 8
90154–06061	20 – 31
	21 – 4
90157–05079	34 – 28
	34 – 39
90164–05014	39 – 3
90167–04X00	12 – 44
90170–06128	4 – 12
90170–18003	3 – 23
90170–20274	16 – 5
90170–20327	16 – 20
90176–22081	24 – 7
90179–05523	36 – 7
90179–06403	21 – 6
90179–06520	36 – 13
90179–08442	12 – 22
90179–16448	3 – 9
90179–18003	17 – 34
90179–25615	24 – 4
90183–05812	27 – 9
90185–06837	38 – 10
	38 – 21
	42 – 6
90185–12119	22 – 22
90201–047A2	44 – 21
90201–05X08	37 – 5
90201–06072	43 – 11
90201–06X04	27 – 8
90201–06X14	41 – 5
	41 – 28
90201–06X28	26 – 36
	26 – 40
90201–08083	35 – 23
90201–082H0	20 – 20
90201–086A3	12 – 49
90201–08M03	26 – 28
90201–08X18	15 – 10
90201–08X19	16 – 25
90201–096J9	1 – 9
90201–100L3	35 – 6
90201–10141	24 – 13
90201–101A4	2 – 5
90201–101J1	23 – 6
90201–10X07	33 – 18
	35 – 30
90201–10X17	16 – 30
90201–10X18	15 – 7
90201–10X21	34 – 6
90201–124G9	22 – 23
	22 – 27
90201–12541	6 – 10
90201–12X05	18 – 19
90201–12X06	18 – 16
90201–16013	3 – 8
90201–16021	22 – 10
90201–17X01	18 – 18
90201–208G4	17 – 23
90201–220T0	24 – 8
90201–30X00	3 – 15
90201–30X01	15 – 3
90202–08X01	26 – 46
90202–26142	24 – 5
90209–20012	16 – 3
90209–21351	17 – 9
90209–21X00	17 – 3
	17 – 19
90209–22X00	17 – 8
90209–26348	17 – 15
90215–18X00	3 – 24
90215–20X00	16 – 4
90215–20X01	16 – 19
90215–21X00	17 – 33
90240–08124	35 – 22
90240–10101	34 – 13
	34 – 20
90267–40X01	12 – 26
	12 – 32
90269–07007	7 – 23
90269–08066	22 – 35
90280–05001	3 – 7
90282–05058	3 – 22
90282–07001	16 – 2
90338–05008	27 – 13
90340–14132	8 – 13
90340–14X00	14 – 10
90340–36X00	14 – 12
90380–22111	22 – 3
90387–06014	34 – 33
	34 – 44
90387–06042	7 – 29
	43 – 14
90387–06161	7 – 39
90387–06202	21 – 18
	43 – 7
	44 – 31
90387–065J6	20 – 30
	21 – 2
90387–06648	7 – 34
90387–068L3	40 – 7
90387–068P7	9 – 33
90387–06M31	38 – 22
90387–06X01	27 – 17
	38 – 11
90387–06X02	7 – 19
	7 – 24
	12 – 41
	36 – 3
90387–06X09	36 – 16
90387–06X36	12 – 37
90387–06X38	39 – 11
90387–06X41	41 – 6
90387–06X42	41 – 7
90387–07037	9 – 34
90387–08024	20 – 19
90387–087L3	26 – 27
90387–124V0	22 – 26
90387–126Y1	22 – 13
	22 – 20
90387–127W0	22 – 28
90387–17801	31 – 25
90387–17802	31 – 26
90387–21002	17 – 7
90387–25802	17 – 26
90401–08133	8 – 26
90401–10096	8 – 29
90401–10X03	33 – 17
	35 – 29
90430–05X00	8 – 24
90430–06014	6 – 12
90430–08119	20 – 5
90430–08X01	8 – 27
90430–09002	10 – 3
90430–10X00	8 – 30
90430–12X01	44 – 5
90430–22123	20 – 3
90445–08X05	7 – 42
90445–08X06	7 – 44
90445–11X01	8 – 43
90450–20X01	8 – 45
	20 – 25
90450–32X03	6 – 23
	7 – 6
	7 – 7
	7 – 26
	7 – 27
90450–59001	9 – 20
90450–72003	9 – 2
90462–07X00	13 – 11
90462–16X00	14 – 15
90464–08126	7 – 46
90464–10X03	20 – 41
90464–16005	26 – 44
90464–25004	42 – 20
	43 – 33
90464–32X00	43 – 31
90464–90X00	20 – 37
	43 – 32
90465–10044	1 – 15
90465–10045	2 – 7
90467–07138	9 – 30
90467–08003	7 – 43
	7 – 45
90467–09006	26 – 14
90467–10008	8 – 44
	8 – 46
90467–11090	9 – 13
	9 – 23
90467–11108	9 – 24
	9 – 25
90467–12085	9 – 14
	35 – 20
90467–14015	13 – 14
	13 – 15
90467–14800	9 – 17
90467–17089	11 – 5
	11 – 8
90467–170A0	11 – 9
90467–170A2	9 – 27
90467–17128	9 – 28
90467–17800	20 – 24
90467–17801	9 – 16
90480–01558	39 – 8
90480–11006	41 – 4
90480–12072	20 – 29
90480–12497	21 – 3
90480–12581	12 – 36
90480–13398	15 – 24
90480–14014	7 – 38
90480–14023	40 – 6
90480–15363	7 – 31
	43 – 12
90480–18276	7 – 28
	9 – 36
90501–04X01	8 – 34
90501–06X00	18 – 2
90501–15001	34 – 29
	34 – 40
90501–26X00	16 – 12
90506–25X01	34 – 5
90508–16X00	16 – 23
90508–28777	34 – 12
	34 – 19
90560–17306	31 – 2
91317–05008	8 – 9
91317–05010	26 – 11
91317–05014	37 – 4
91317–06010	34 – 11
	34 – 18
91317–06012	6 – 21
	8 – 31
	14 – 14
	14 – 26
91317–06014	44 – 12
91317–06016	8 – 42
	13 – 17
	26 – 8
91317–06018	1 – 18
91317–06020	6 – 17
	8 – 12
	19 – 4
91317–06025	5 – 14
	8 – 38
	14 – 5
	14 – 35
91317–06030	1 – 8
	13 – 5
	14 – 22
91317–06035	14 – 4
	14 – 34
91317–06040	2 – 6
91317–06045	13 – 6
	14 – 18
91317–06050	6 – 24
	14 – 6
	14 – 7
91317–06055	13 – 7
91317–06060	13 – 8
91317–06080	13 – 9
91317–06090	13 – 10
91317–06095	8 – 22
91317–08025	15 – 9
9131L–06035	9 – 35
9131M–05020	43 – 4
9131M–06020	38 – 9
	38 – 20
91380–06016	11 – 3
91380–08020	12 – 17

PART NO.	REF. NO.
91380–08030	12 – 50
91401–20012	35 – 24
91401–25020	34 – 14
	34 – 21
91808–16X00	13 – 3
	14 – 30
	14 – 33
91810–14X00	8 – 37
92014–08025	35 – 26
92017–05025	44 – 28
92017–06014	27 – 12
92017–06020	27 – 7
	41 – 9
92017–06030	37 – 3
92017–06035	8 – 4
92017–10045	35 – 5
9201L–06014	41 – 21
9201L–06025	41 – 10
92507–06012	9 – 18
92902–04100	33 – 14
92902–04600	33 – 15
92907–04200	41 – 24
92907–05600	42 – 16
92907–06600	9 – 19
9290L–04600	12 – 27
	12 – 33
9290L–05200	41 – 18
9290M–05600	43 – 5
9290M–06200	40 – 9
93101–12173	6 – 8
93101–14164	14 – 24
93101–25106	3 – 21
93102–12106	18 – 14
93102–15212	16 – 28
93102–35368	17 – 28
93106–22019	22 – 4
93106–23002	28 – 4
	31 – 4
93106–30029	31 – 8
93108–35004	22 – 6
93109–17071	22 – 12
	22 – 19
93210–07X01	8 – 20
	13 – 4
93210–10X00	8 – 36
93210–11X00	8 – 16
93210–13X00	8 – 3
	14 – 8
93210–14X00	14 – 11
93210–15414	35 – 4
93210–15620	35 – 9
93210–15X00	8 – 41
93210–19123	20 – 23
93210–21X00	6 – 20
93210–22X00	17 – 27
93210–29X00	44 – 2
93210–33X00	6 – 18
93210–35X00	14 – 13
93210–41X00	7 – 4
93210–61750	6 – 4
93210–64X01	8 – 19
93210–78X00	1 – 17
93210–92X01	26 – 6
93210–96X00	1 – 13
93211–04X00	26 – 7
93306–00106	6 – 5
93306–00304	16 – 9
93306–004XL	17 – 12
93306–004XM	17 – 31
93306–07209	5 – 2
93306–20348	31 – 3
93306–203XN	28 – 3
93306–205XA	17 – 11
93306–30437	31 – 6
93306–305X4	17 – 25
93306–305YH	3 – 20
93306–305YJ	3 – 19
93306–308Y0	3 – 10
93310–530C7	15 – 2
93310–84010	3 – 5
93315–11206	18 – 13
93315–22251	22 – 2
93315–31502	16 – 29
93315–31758	22 – 18
93317–11096	16 – 27
93317–21746	22 – 11
	22 – 16
93317–31771	22 – 17
93332–00001	24 – 2
93332–00008	24 – 1
93410–10X00	16 – 31
93410–11X00	8 – 6
93410–17X00	18 – 17
93410–20825	17 – 24
93440–11024	15 – 13
93440–25084	17 – 4
93440–25084	17 – 20
93440–28062	17 – 16
93450–24824	3 – 14
93501–04011	34 – 30
	34 – 41
93503–08007	8 – 33
93603–16219	6 – 13
93612–16X00	1 – 11
94109–21800	28 – 7
94109–21801	28 – 7
94113–17800	31 – 15
94113–17801	31 – 15
94418–21X00	28 – 5
94427–17X00	31 – 14
9456X–08110	31 – 19
94591–57126	5 – 9
94701–00X09	1 – 10
95024–06012	33 – 19
95024–06025	21 – 5
95027–06008	44 – 15
95027–06012	5 – 7
	22 – 32
95027–06014	26 – 17
	26 – 19
95027–06020	1 – 14
	7 – 3
95027–06025	6 – 7
	14 – 31
95602–06200	27 – 18
95604–06200	34 – 34
	34 – 45
95604–16200	22 – 9
	31 – 27
95607–05200	44 – 29
95607–06200	43 – 8
95607–08200	34 – 24
	39 – 7
95607–10200	20 – 8
	20 – 12
	20 – 15
	20 – 34
	23 – 5
	24 – 14
	31 – 11
95607–12200	23 – 3
95617–06100	33 – 8
95617–08618	1 – 3
95617–12100	22 – 25
9561M–10100	34 – 7
95707–08500	31 – 24
9570L–04300	41 – 25
9570L–05300	41 – 17
9570L–06500	43 – 2
9571L–06300	41 – 29
	44 – 7
95807–06008	21 – 16
95807–06010	20 – 40
95807–06016	21 – 15
	21 – 17
95807–06040	43 – 13
95812–06030	25 – 50
95817–06035	15 – 22
	40 – 8
95817–06040	34 – 32
	34 – 43
95817–06050	36 – 17
95817–08014	12 – 48
95817–08030	27 – 21
95817–08040	26 – 30
95817–08045	39 – 6
95817–10035	20 – 33
95817–10070	20 – 7
9581M–06012	20 – 27
	44 – 26
9581M–06014	44 – 30
9581M–06016	41 – 27
9581M–08012	20 – 4
95827–08040	20 – 21
97017–06025	36 – 2
97707–40010	27 – 25
97707–40012	41 – 2
97707–40014	27 – 27
97707–40020	41 – 22
97707–40025	44 – 20
9770L–30110	41 – 14
9770M–50030	9 – 8
98502–04012	33 – 13
98507–05020	42 – 18
98507–05030	42 – 12
98507–05045	42 – 13
	42 – 17
98507–05055	42 – 15
98507–06012	10 – 4
98580–04016	25 – 48
98707–03020	42 – 10
99001–07600	16 – 26
99001–10600	18 – 15
99009–12400	6 – 15
99530–12016	13 – 2
	14 – 3
	14 – 9
	14 – 21
99530–14016	13 – 18